

A.A. Linero, P.E.
Program Administrator
Air Permitting South Section
Bob Martinez Center
2600 Blair Stone Road
Tallahassee, FL 32399-2400
alvaro.linero@dep.state.fl.us

VIA EMAIL

**Subject: Protocol - Class I Area Impact Analysis
DEP file No. 0930104-AC
Okeechobee Landfill Expansion and Addition of Control Equipment**

Dear Mr. Linero;

We are pleased to submit the protocol for the Class I Area Impact Analysis for your review and comment. We are available to meet or conference with you to discuss the contents of this protocol should you or your staff so desire.

Sincerely,



Kelly Fagan
Client Program Manager

Attachment: Class I Area Impact Analysis for Proposed Expansion In Okeechobee Landfill,
December 2007

Cc: D. Nelson, FDEP Air Permitting Section, deborah.nelson@dep.state.fl.us
M. Stallard, Okeechobee Landfill, Inc., mstallard@wm.com
J. Fasulo, Okeechobee Landfill, Inc., jfasulo@wm.com
D. Thorley, Okeechobee Landfill, Inc., dthorley@wm.com
A. Pakrasi, Shaw Environmental, Inc., arijit.pakrasi@shawgrp.com
B. Maillet, Shaw Environmental, Inc., bruce.maillet@shawgrp.com
K. Alzheimer, Shaw Environmental, Inc., kris.alzheimer@shawgrp.com


PROTOCOL

CLASS I AREA IMPACT ANALYSIS FOR PROPOSED EXPANSION IN OKEECHOBEE LANDFILL

Prepared for:

**Okeechobee Landfill, Inc.
Okeechobee, Florida**

Prepared by:


Shaw® Shaw Environmental, Inc.
Shaw Environmental, Inc.
Monroeville, Pennsylvania

Project No. 121525
December 2007

Table of Contents

List of Tables	iii
List of Figures	iii
List of Appendices	iii
1.0 Introduction	1
2.0 Background Information	3
2.1 Description of Site	3
2.2 Description of Emission Sources	3
2.3 Elements of Class I Area Impact Analysis	6
2.4 Existing Environmental Conditions in the Everglades National Park	8
2.5 Existing Conditions at Biscayne Bay National Park and Big Cypress National Preserve.....	12
3.0 Technical Approach and Methodology	13
3.1 Long Range Transport Model	13
3.2 Source Parameters.....	21
3.3 Load Analysis	24
3.4 Building Downwash Analysis	24
3.5 Meteorological Data.....	24
3.6 Receptor Layout	25
3.7 Background Concentrations of Ammonia and Ozone	25
3.8 Background Light Extinction Coefficient	25
3.9 Ammonia Limiting Method	25
3.10 Relative Humidity Method.....	26
3.11 Monthly Background Concentrations.....	26
3.12 Rayleigh Scattering Coefficient	26
3.13 Particle Size Fractions.....	27
4.0 Compliance Demonstration.....	28
4.1 Air Quality	28
4.2 Deposition Flux.....	28
4.3 Visibility Impact.....	28
5.0 Report Format.....	30

List of Tables

Table 2-1	Q/D Analysis for Emission Sources
Table 2-2	Reference Concentrations of Regulated Pollutants for Class I Impact Analysis
Table 3-1	Major Features of CALPUFF Model Used in the Analysis
Table 3-2	Regulatory Defaults used in CALPUFF
Table 3-3	Modeled Emissions Rate
Table 3-4	Modeled Stack Parameters
Table 3-5	Load Analysis for Combustion Turbine
Table 3-6	Monthly Background Concentrations (ug/m ³)

List of Figures

Figure 2-1	Location of Okeechobee Landfill
Figure 2-2	Plot Plan of Okeechobee Landfill
Figure 3-1	Receptor Layout in Everglades National Park
Figure 3-2	Receptor Layout for Biscayne Bay National Park
Figure 3-3	Receptor Layout for Big Cypress National Preserve

List of Appendices

Appendix A	OEPA Engineering Guide #69
------------	----------------------------

1.0 Introduction

The Okeechobee Landfill Facility (Facility), which is owned and operated by Okeechobee Landfill, Inc. (OLI), is comprised of an existing municipal solid waste (MSW) landfill and supporting operations. The facility has been operational since 1981 and under the existing solid waste permit will continue to construct and operate the landfill until approximately 2058. The landfill is an emission unit for nonmethane organic compounds (NMOCs) and hazardous air pollutants (HAPs), which are landfill gas (LFG) constituents. The typical control device for NMOCs and HAPs in LFG is flaring of the gas. Combustion can also be achieved by engines and turbines. The proposed project includes the construction of a landfill-gas-to-energy (LFGTE) plant as the primary control devices. The LFGTE plant will consist of LFG turbines with flares as a back up option.

The Facility currently has two enclosed landfill gas flares with Evap® systems and an open, utility flare as a backup. The two enclosed flares and the backup flare are operated under the current Title V operation permit. There is currently an odor control flare that is operating under a first amended order between FDEP and Okeechobee Landfill Inc.. A second amended order allows up to five flares to be operated at the Facility. The estimated maximum potential-to-emit (PTE) based on LFG generation estimates occurs shortly after closure in 2058 and will increase from current 6,000 standard cubic feet per minute (scfm) to 32,400 scfm. There is a current need to install more flaring capacity for control of collected LFG; however, as the landfill construction is ongoing, turbines will be installed and landfill gas will be diverted from the flares to the gas turbines, which will beneficially use the landfill gas by converting it into electricity. Under this scenario, the landfill gas will always be combusted in turbines (numbers increasing with time) and two flares to combust residual gas after full capacity is achieved in turbines. As the gas generation reaches the maximum for the flare, the gas will be transferred to a new turbine, and the flares will be ready for excess gas generated from the landfill. In addition to controlling landfill gas by combustion, the air construction permit includes a landfill gas pretreatment system identified as LoCat™ in the Best Available Control Technology (BACT) analysis. After the BACT is installed, LFG will be treated before directed to the flares and turbines.

Although the Facility is not a permitted as a major stationary source under PSD, recent fuel analysis for hydrogen sulfide indicates that the actual emissions after typical LFG control do qualify the Facility as a major stationary source. Additionally, the expected emission increases from the current level to the predicted levels at the completion of the landfill construction are above the significant emission rate therefore, triggering PSD review under Chapter 62-212.400.

The Application provides the information required by Chapter 62-212.400, F.A.C., for Prevention of Significant Deterioration (PSD) review.

The net emissions from the proposed changes in the facility exceeded the significant emission rates for New Source Review (NSR) for the following pollutants: SO₂, NO_x, PM₁₀, and CO. Therefore, a Best Available Control Technology (BACT) analysis was conducted. Near field air quality impact analysis for demonstration of compliance with PSD Class II increments and NAAQS is also being conducted.

An important element of the air quality analysis is the Class I area impact analysis. The analysis requires estimation of impact of the proposed project on nearby federally designated Class I areas in terms of air quality, acidic deposition, and visibility degradation, which are part of the air quality related values (AQRVs).

This protocol provides details of the Class I area impact analysis to be conducted for the proposed changes in the Okeechobee Landfill facility (facility). The Protocol is arranged as follows:

- Section 2.0: Background Information
- Section 3.0: Technical Approach and Methodology
- Section 4.0: Compliance Demonstration
- Section 5.0: Report Format

2.0 Background Information

2.1 Description of Site

The Facility is located in Okeechobee County in Central Florida near Lake Okeechobee at approximately 27°20'24" latitude and 80°41'27" longitude. Figure 2-1 shows the site within the state of Florida and nearby natural features. The 4300 acre site contains the existing Berman Road Landfill, the proposed Clay Farms expansion, and auxiliary services.

The terrain surrounding the Facility is mostly flat with terrain heights reaching 60 feet within 5 kilometers (km) from the property boundary line. The vegetation is mostly grassland and mangroves. Land use in the surrounding area is mostly rural. A large water body (Lake Okeechobee) is located approximately 30 km southwest of the Facility.

The area is not industrial and there are no large industrial sources within 10 km from the Facility. Okeechobee County is in attainment for all regulated pollutants with federal NAAQS and FDEP AAQS. The nearest Class I area is Everglades National Park (NP) approximately 169 km south of the southernmost property boundary of the Facility. FDEP has also requested a Class I analysis for two other Class II areas, Biscayne Bay NP and Big Cypress National Preserve. Biscayne Bay is located approximately 193.5 km from the sources and Big Cypress is located approximately 121 km from the sources.

There is no meteorological monitoring station in the Facility. Meteorological data from nearest National Weather Service (NWS) station in West Palm Beach (approximately 60 km southeast of Facility) shows a predominantly westerly wind pattern. Climatological data shows that average and maximum wind speed in the area are approximately 4 meters per second (m/s) and 10 m/s. Average annual rainfall in the area is 1560 millimeter (mm).

Figure 2-2 shows a plot plan for the existing Facility. The location of the existing flares and the locations of the proposed turbines and proposed flares are also shown in Figure 2-2.

2.2 Description of Emission Sources

The current and future operations have been described in detail in Section 2.0 and 3.0 of the Air Permit Application and are summarized here.

1. There is an interim scenario for the facility in which the final construction permit is issued and the construction commences. The construction includes the sulfur control equipment which must be procured, designed, manufactured and installed. There are two alternatives under the interim scenario: 1) the addition of open flares to control the

increasing LFG generation and 2) the addition of open flares and the replacement of the existing enclosed flares.

2. The routine BACT Scenario will consist of a LFGTE plant and backup flares. The alternative operating BACT scenario considers flaring all of the LFG. (A combination of these two scenarios may be implemented depending on the operational needs of the facility.) Since the facility is considering the replacement of the existing enclosed flares with new open flares, the alternative BACT scenario includes two options: 1) the addition of 8 new open flares with the existing enclosed flares and 2) the addition of 8 new flares and replacing the two existing flares.

BACT scenarios will have BACT installed for SO₂ as described in the initial permit application.

For the purpose of air quality analysis, the following LFG combustion emission sources have been considered:

i) Interim Scenario 1:

- Two existing enclosed flares (CD001 and CD002) used as control devices rated at 3,000 of LFG each; and
- Two new open flares (CD003 and CD004) used as control devices rated at 3,300 scfm of LFG.
- Total potential flow of 12,600 scfm.

ii) Interim Scenario 2:

- Two new open flares (CD018 and CD019) used as control devices replacing the existing enclosed flares (CD001 and CD002) rated at 3,300 scfm of LFG; and
- Two new open flares (CD003 and CD004) used as control devices rated at 3,300 scfm of LFG.
- Total potential flow of 13,200 scfm.

iii) Routine Operating Scenario (BACT Scenario):

- Seven LFG turbines (CD011 to CD017) used as control devices each rated at 4,000 scfm of LFG;
- One open flare (CD003) used as a control device rated at 3,300 scfm of LFG; and
- One open flare (CD004) used as a control device rated at 3,300 scfm LFG, but only operating at one third capacity (1,100 scfm).
- Total potential flow of 32,400 scfm

- iv) Alternative BACT Operating Scenario 1 (in case gas turbines are unavailable)
 - Eight new open flares (CD003 through CD010) used as control devices each rated at 3,300 scfm of LFG
 - Two existing enclosed flares (CD001 and CD002) used as control devices each rated at 3,000 scfm of LFG
 - Total potential flow of 32,400 scfm
- v) Alternative BACT Operating Scenario 2 (in case gas turbines are unavailable)
 - Eight new open flares (CD003 through CD010) used as control devices each rated at 3,300 scfm of LFG
 - One new open flare (CD018) used as a control device replacing the existing enclosed flare (CD001) rated at 3,300 scfm of LFG
 - One new open flare (CD019) used as a control device replacing the existing enclosed flare (CD002) rated at 3,300 scfm of LFG, but only operating at 2,700 scfm.
 - Total potential flow of 32,400 scfm

The emission rates used for the air quality analysis from these emission sources are described in Section 3.2.

The pollutants considered for the Class I impact analyses are: i) NO_x, ii) SO₂; and iii) PM₁₀. Other pollutants such as sulfates, nitrates, ammonia, sulfuric acid mist, and nitric acid mist are not emitted from the emission sources in any appreciable amounts. The total emissions of these pollutants and distance of the emission sources from the Everglades NP, Biscayne Bay NP, and Big Cypress National Preserve are shown in Table 2-1.

Table 2-1a: Q/D Analysis for Emission Sources for Everglades National Park

Operating Scenario	Distance to Everglades (km)	Total SO ₂ Emissions (tpy)	SO ₂ Q/D (tpy/km)	Total NO _x Emissions (tpy)	NO _x Q/D (tpy/km)	Total PM ₁₀ Emissions (tpy)	PM Q/D (tpy/km)
Interim 1	174	1341.2	7.7	106.3	0.6	25.9	0.1
Interim 2	174	1405.1	8.1	117.9	0.7	27.1	0.2
Routine BACT	174	574.7	3.3	991.8	5.7	76.7	0.4
Alternative BACT 1	174	574.7	3.3	283.2	1.6	66.6	0.4
Alternative BACT 2	174	574.7	3.3	289.5	1.7	66.6	0.4

Table 2-1b: Q/D Analysis for Emission Sources for Biscayne Bay National Park

Operating Scenario	Distance to Biscayne Bay (km)	Total SO2 Emissions (tpy)	SO2 Q/D (tpy/km)	Total NOx Emissions (tpy)	NOx Q/D (tpy/km)	Total PM10 Emissions (tpy)	PM Q/D (tpy/km)
Interim 1	193.5	1341.2	6.9	106.3	0.5	25.9	0.1
Interim 2	193.5	1405.1	7.3	117.9	0.6	27.1	0.1
Routine BACT	193.5	574.7	3.0	991.8	5.1	76.7	0.4
Alternative BACT 1	193.5	574.7	3.0	283.2	1.5	66.6	0.3
Alternative BACT 2	193.5	574.7	3.0	294.9	1.5	66.6	0.3

Table 2-1c: Q/D Analysis for Emission Sources for Big Cypress National Preserve

Operating Scenario	Distance to Big Cypress (km)	Total SO2 Emissions (tpy)	SO2 Q/D (tpy/km)	Total NOx Emissions (tpy)	NOx Q/D (tpy/km)	Total PM10 Emissions (tpy)	PM Q/D (tpy/km)
Interim 1	121	1341.2	11.1	106.3	0.9	25.9	0.2
Interim 2	121	1405.1	11.6	117.9	1.0	27.1	0.2
Routine BACT	121	574.7	4.7	991.8	8.2	76.7	0.6
Alternative BACT 1	121	574.7	4.7	283.2	2.3	66.6	0.6
Alternative BACT 2	121	574.7	4.7	294.9	2.4	66.6	0.6

2.3 Elements of Class I Area Impact Analysis

Florida’s State Implementation Plan (SIP), which contains the PSD regulations, has been approved by USEPA and therefore PSD approval authority has been granted to FDEP. FDEP’s PSD regulations are codified in Rule 62.212.200, Florida Administrative Code (F.A.C.) and are same as the federal PSD regulations codified in 40 CFR Part 51.166.

Class I areas are areas of special national or regional value from a natural, scenic, recreational, or historic perspective. Adverse impacts on Class I areas are prevented by:

- i) Ensuring that Class I area increments are not exceeded; and
- ii) Ensuring that the air quality related values (AQRVs) in the Class I areas are not significantly affected.

Typically, Class I area within 100 km of the proposed source or modification is considered in the analysis. Currently, due to current emphasis in improving visibility in Class I areas via the Regional Haze Rule, Class I areas at greater distances are also being included in the analysis.

The Federal Class I area nearest to the source is the Everglades NP in South Florida, located approximately 169 kilometers from the facility's southern most property line. The Biscayne Bay NP and Big Cypress National Preserve are Class II areas; however, they are considered important relative to air pollution impacts and will also be considered in the analysis.

The Class I area air quality analysis will be conducted in two phases.

- i) Significant Impact Analysis: The net emissions increase from project will be used in determining the air quality impact in the Class I area and will then be compared to the Class I area significance levels concentration. The Draft New Source Review Workshop Manual (1990) lists Class I significance level concentration as 1 ug/m^3 for 24-hour average for all pollutants with NAAQS. USEPA has subsequently proposed lower significance level concentration as shown in Table 2-2. These levels in Table 2-2 have not been officially promulgated as part of the PSD review process. However, FDEP has accepted the use of these significance level concentration for Class I areas.

Since Biscayne Bay NP and Big Cypress National Preserve are Class II areas. The significance level concentrations for Class II areas will be compared to the modeling results. The Class II significance level concentrations are shown in Table 2-2.

If the project's air quality impact does not exceed the Class I or Class II significance level concentration, then Class I area PSD increment analysis is not required.

- ii) Class I area PSD Increment and AQRV Analysis: The PSD Increment analysis will be needed if the project's air quality impact exceeds the Class I or Class II area significance level concentration.

The AQRV analysis is required for submission to Federal land Managers (FLM) who are charged with affirmative responsibility to protect the AQRVs. The AQRVs vary with the Class I area being considered. Based on discussions with the National Park Service (NPS), the AQRVs to be considered for the Everglades NP, Biscayne Bay NP, and Big Cypress National Preserve are: i) deposition of total nitrates and sulfates; and ii) visibility impairment. The results of these analyses will be submitted to NPS.

**Table 2-2
Reference Concentrations of Regulated Pollutants for Class I Impact Analysis**

Pollutant	Averaging Period	Current USEPA Class I Significance Level (ug/m3)	Proposed USEPA Class I Significance Level (ug/m3)	USEPA Class II Significance Level (ug/m3)
NO ₂	Annual	N/A	0.1	1
	24-hr	1	N/A	N/A
SO ₂	3-Hour	N/A	1	25
	24-Hour	1	0.2	5
	Annual	N/A	0.1	1
PM ₁₀	24-Hour	1	0.3	5
	Annual	N/A	0.2	1

Notes:

1: Proposed Class I significance levels are guidelines at this time and has not been adopted in PSD regulations.

2.4 Existing Environmental Conditions in the Everglades National Park

Not a sentence:

The existing environmental conditions of the Class I area are important and have been considered in the analysis. Some of the Class I areas may show significant impact in concentrations or deposition which would be tolerable in other Class I areas. The following information was obtained from the NPS website for the Everglades NP.

Established in 1947 to preserve the biological features and essential primitive conditions of the subtropical everglades of Florida, this Class I NP is the largest U.S. national park east of the Rocky Mountains. Spanning the southern tip of the Florida peninsula and most of Florida Bay, Everglades NP is the only subtropical preserve in North America. It contains both temperate and tropical plant communities, including sawgrass prairies, mangrove and cypress swamps, pinelands, and hardwood hammocks, as well as marine and estuarine environments. It is the largest continuous stand of sawgrass prairie in North America and the predominant water recharge area for all of South Florida. Everglades NP is consistently listed as one of the most threatened national parks, due primarily to hydrological developments that have disrupted water flow with serious ecological consequences. The park encompasses 1,509,000 acres, of which 1,296,500 acres are designated wilderness. Everglades NP was designated a Biosphere Reserve in 1976, a World Heritage Site in 1979, and a Wetland of International Importance in 1987.

A National Atmospheric Deposition Program/National Trends Network (NADP/NTN) wet deposition monitor has been operating at Everglades NP since 1980 (site #FL11). A review of site data shows no trend in concentration of sulfate or nitrate, and an increase in concentration of

ammonium. Wet sulfate, nitrate, and ammonium deposition decreased from 1981 through 1985, and then increased from 1989 through the present.

A Clean Air Status and Trends Network (CASTNet) dry deposition site was installed at Everglades NP (site #EVE418) in 1998. Data show no trends in dry nitrogen or sulfur deposition at the site.

Ozone has been continuously monitored at Everglades NP since 1986 (site #120250030). The data indicate no exceedances of the 1-hr human health-based primary National Ambient Air Quality standards.

Ambient Air Quality:

South Florida is in attainment status for all criteria pollutants. FL does have AQM areas for ozone – including Palm Beach and Broward counties,

Ozone has been continuously monitored at Everglades NP since 1986 (site #120250030). The data indicate no exceedances of the 1-hr human health-based primary National Ambient Air Quality Standards.

Acidic Deposition:

A National Atmospheric Deposition Program/National Trends Network (NADP/NTN) wet deposition monitor has been operating at Everglades NP since 1980 (site #FL11). A review of site data shows no trend in concentration of sulfate or nitrate, and an increase in concentration of ammonium. Wet sulfate, nitrate, and ammonium deposition decreased from 1981 through 1985, and then increased from 1989 through the present.

A Clean Air Status and Trends Network (CASTNet) dry deposition site was installed at Everglades NP (site #EVE418) in 1998. Data show no trends in dry nitrogen or sulfur deposition at the site.

Deposition of atmospheric nitrogen contributes to overenrichment and eutrophication in Everglades NP and Florida Bay. Excess nutrient loading has resulted in algae blooms and loss of seagrasses in Florida Bay.

Threatened and Endangered Species:

Drainage of wetlands, alteration of overland water flow and hunting have all contributed to species decline. The Everglades, once known for its abundant bird life, has seen its wading bird population decline drastically since the turn of the century. The Florida Panther once common throughout the state is on the verge of extinction today. Within the four National Park areas of Everglades NP, Biscayne NP, Big Cypress National Preserve and Fort Jefferson National

Monument there are 16 endangered and 6 threatened wildlife species. The mere physical boundaries of a national park do not guarantee a species survival.

For the last decade the South Florida Research Center, Everglades NP, has been studying how changes occurring outside the parks influence the fragile areas within their boundaries. Research going on today may lead to a brighter future for many species. Known endangered species in Everglades NP are:

- American crocodile (*Crocodylus acutus*)
- Green turtle (*Chelonia mydas*)
- Atlantic Ridley turtle (*Lepidochelys kempi*)
- Atlantic hawksbill turtle (*Eretmochelys imbricata*)
- Atlantic leatherback turtle (*Dermochelys coriacea*)
- Cape Sable seaside sparrow (*Ammodramus maritima mirabilis*)
- Snail (Everglades) kite (*Rostrhamus sociabilis plumbeus*)
- Wood stork (*Mycteria americana*)
- West Indian manatee (*Trichechus manatus*)
- Florida panther (*Felis concolor coryi*)
- Key Largo wood rat (*Neotoma floridana smalli*)
- Key Largo cotton mouse (*Peromyscus gossypinus allapaticola*)
- Red-cockaded woodpecker (*Picooides borealis*)
- Schaus swallowtail butterfly (*Papilio aristodemus ponceanus*)
- Garber's Spurge (*Chamaesyce garberi*)

Plants and Habitats:

The Everglades is a low, flat plain shaped by the action of water and weather. In the summer wet season it is a wide, grassy river. In the winter season the edge of the slough is a dry grassland. Though Everglades NP is often characterized as a water marsh, several very distinct habitats exist within its boundaries.

Marine/Estuarine

Florida Bay, the largest body of water within Everglades NP, contains over 800 square miles (2072 square km) of marine bottom, much of which is covered by seagrass. The seagrass shelters fish and shellfish and sustains the food chain that supports all higher vertebrates in the bay.

Mangroves

Mangrove forests are found in the coastal channels and winding rivers around the tip of South Florida. Red mangroves (*Rhizophora mangle*), identified by their stilt-like roots, and the black (*Avicennia germinans*) and white mangroves (*Laguncularia racemosa*) thrive in tidal waters, where freshwater from the Everglades mixes with saltwater.

Coastal Prairie

Located between the tidal mud flats of Florida Bay and dry land, the coastal prairie is an arid region of salt-tolerant vegetation periodically flooded by hurricane waves and buffeted by heavy winds. It is characterized by succulents and other low-growing desert plants that can withstand the harsh conditions.

Freshwater Marl Prairie

Bordering the deeper sloughs are large prairies with marl sediments, a calcareous material that settles on the limestone. The marl allows slow seepage of the water but not drainage. Though the sawgrass is not as tall and the water is not as deep, freshwater marl prairies look a lot like freshwater sloughs.

Freshwater Slough

The slough is the deeper and faster-flowing center of a broad marshy river. This "fast" flow moves at a leisurely pace of 100 feet (30 meters) per day. Dotted with tree-islands called hammocks or heads, this vast landscape channels life-giving waters from north to south. Everglades NP contains two distinct sloughs: Shark River Slough, the "river of grass;" and Taylor Slough, a narrow, eastern branch of the "river."

Cypress

The cypress tree (*Taxodium spp.*) is a deciduous conifer that can survive in standing water. These trees often form dense clusters called cypress domes in natural water-filled depressions. The trees in the deep soil at the center grow taller than those on the outside. Stunted cypress trees, called dwarf cypress, grow thinly-distributed in poor soil on drier land.

Hardwood Hammocks

Hammocks are dense stands of hardwood trees that grow on natural rises of only a few inches in the land. They appear as teardrop-shaped islands shaped by the flow of water in the middle of the slough. Many tropical species such as mahogany (*Swietenia mahogoni*), gumbo limbo (*Bursera simaruba*), and cocoplum (*Chrysobalanus icaco*) grow alongside the more familiar temperate species of live oak (*Quercus virginiana*), red maple (*Acer rubum*), and hackberry (*Celtis laevigata*). Because of their slight elevation, hammocks rarely flood. Acids from decaying plants dissolve the limestone around each tree island, creating a natural moat that protects the hammock plants from fire. Shaded from the sun by the tall trees, ferns and airplants thrive in the moisture-laden air inside the hammock.

Pinelands

The slash pine (*Pinus elliottii* var. *densa*) is the dominant plant in this dry, rugged terrain that sits on top of a limestone ridge. The pines root in any crack or crevice where soil collects in the jagged bedrock. Fire is an essential condition for survival of the pine community, clearing out the faster-growing hardwoods that would block light to the pine seedlings. Pine bark is multi-layered, so only the outer bark is scorched during fires. The pinelands are the most diverse habitat in the Everglades, consisting of slash pine forest, spelling? an understory of saw palmettos (*Serenoa repens*), and over 200 varieties of tropical plants.

2.5 Existing Conditions at Biscayne Bay National Park and Big Cypress National Preserve

Information is being collected on Biscayne Bay NP and Big Cypress National Preserve and the conditions there are expected to be similar to the Everglades NP.

3.0 Technical Approach and Methodology

Air dispersion and deposition modeling will be performed to determine ambient concentrations, deposition, and visibility impacts of the proposed modification on the Everglades NP, Biscayne Bay NP, and Big Cypress National Preserve, generally in conformance with the following guideline documents, with appropriate modifications based on site-specific data:

- Interagency Workgroup on Air Quality Models (IWAQM) Phase 2 Summary report in Modeling Long Range Transport Impacts (USEPA,1998), commonly referred to as IWAQM Phase 2 Report;
- Federal Land Manager's Air Quality Related Values Workgroup, Phase I Report (12/00), commonly referred to as the FLAG Document.
- CALPUFF User's Guide January 2000

The elements of the analysis have been described in Section 2.3. The rest of this section describes the methodology of the modeling and input data for the model.

3.1 Long Range Transport Model

The California Puff Model (CALPUFF) is currently recommended by USEPA for long range transport of pollutants and for visibility impact analysis. The USEPA has approved an update in CALPUFF from V5.711a (dated July 16, 2004) to V5.8 (dated June 23, 2007). This version will be used in this analysis.

The CALPUFF is a multi-layer, multi-species, non-steady state puff dispersion model which can simulate the time and space varying meteorological conditions on pollutant transport, transformation, and removal. CALPUFF uses three-dimensional meteorological fields developed by the meteorological processing program CALMET.

CALPUFF contains algorithms for near source effects such as building downwash, traditional plume rise, partial plume penetration, subgrid scale terrain interactions, as well as long range effects such as pollutant removal (dry and wet deposition), chemical transformation, vertical wind shear, overwater transport, and coastal interaction effects. Major features of the CALPUFF model are shown in Table 3-1.

Table 3-1

Major Features of CALPUFF Model

Feature Element	Details
Source Type	Point, Line, Volume, Area
Non-steady-state emissions and meteorological conditions	Gridded 3-D fields of meteorological variables
	Spatially-variable fields of mixing height, friction velocity, convective velocity scale, Monin-Obukhov length, precipitation rate
	Vertically and horizontally-varying turbulence and dispersion rates
	Time-dependent source and emissions data
Efficient sampling function	Integrated and Elongated puff formulation
Dispersion coefficient options	Direct measurements of dispersion coefficient
	Estimated values of coefficients based on similarity theory
	Pasquill-Gifford dispersion coefficients
	McElroy-Pooler dispersion coefficients
Vertical wind shear	CTDM dispersion coefficients
	Puff splitting
Plume rise	Differential advection and dispersion
	Partial penetration
	Buoyant and momentum rise
	Stack tip effects
	Vertical wind shear
Building Downwash	Building downwash effects
	Huber-Snyder method
Subgrid scale complex terrain	Schulman-Scire Method
	Above dividing streamline, puff flows over hill and experiences altered diffusion rates
Interface to the Emissions Production Model	Below dividing streamline, puff deflects around hill, splits, and wraps around hill
	Time-varying heat flux and emissions from controlled burns and wildfires
Dry deposition	Gases and particulate matter
	Full treatment of space and time variations of deposition with a resistance model option
	User-specified diurnal cycles for each pollutant option
	No dry deposition option

Feature Element	Details
Overwater and coastal interaction effects	Overwater boundary layer parameters
	Abrupt change in meteorological conditions, plume dispersion at coastal boundary
	Plume fumigation
	Option to introduce subgrid scale Thermal Internal Boundary Layers into coastal grid cells
Chemical transformation options	MESOPUFF II method
	User-specified diurnal cycles of transformation rates
	No chemical conversion
Wet removal	Scavenging coefficient approach
	Removal rate a function of precipitation intensity and type
Graphical user interface	Point-and-click model setup and data input
	Enhanced error checking of model inputs
	On-line Help files

To estimate the concentration, deposition, and visibility impacts, the results from CALPUFF model will be processed with post processing utilities CALPOST and POSTUTIL.

The regulatory defaults of the CALPUFF model will be used and are listed in Table 3-2.

Table 3-2

Regulatory Defaults Used in CALPUFF

Parameter	Description	Value	Units
AVET	Averaging Time	60	minutes
PGTIME	PG Averaging Time	60	minutes
MGAUSS	Vertical distribution used in the near field (Gaussian)	1	dimensionless
MCTADJ	Terrain adjustment method (partial plume path adjustment)	3	dimensionless
MCTSG	Subgrid-scale complex terrain model	No	dimensionless
MSLUG	Near-field puffs modeled as elongated slugs	No	dimensionless

MTRANS	Transitional plume rise modeled	Yes	dimensionless
MTIP	Stack tip downwash	Yes	dimensionless
MSHEAR	Vertical wind shear modeled above stack tip	No	dimensionless
MSPLIT	Puff splitting allowed	No	dimensionless
MCHEM	Chemical mechanism flag (MesoPuff II scheme)	1	dimensionless
MAQCHEM	Aqueous phase transformation modeled	No	dimensionless
MWET	Wet removal modeled	Yes	dimensionless
MDRY	Dry deposition modeled	Yes	dimensionless
MDISP	Method used to computer dispersion coefficients (ISCT PG for rural and MP for urban)	3	dimensionless
MROUGH	PG sigma-y,z adjustment for roughness	No	dimensionless
MPARTL	Partial plume penetration of inversion	Yes	dimensionless
MPDF	PDF used for dispersion under convective conditions (AERMOD)	No	dimensionless
MSGTIBL	Sub-grid TIBL module used for shore lines	No	dimensionless
MESHDN	Nesting factor of the sampling	1	dimensionless
RCUTR	Reference cuticle resistance	30	s/cm
RGR	Reference ground resistance	10	s/cm
REACTR	Reference pollutant reactivity	8	dimensionless

NINT	Number of particle-size intervals used to evaluate effective particle deposition velocity	9	No.
IVEG	Vegetation state in unirrigated areas (Active and unstressed vegetation)	1	dimensionless
RNITE1	Nighttime SO ₂ loss rate	0.2	%/hr
RNITE2	Nighttime NO _x loss rate	2.0	%/hr
RNITE3	Nighttime HNO ₃ formation rate	2.0	%/hr
MXSAM	Maximum number of sampling steps for one puff/slug during one time step	99	No.
NCOUNT	Number of iterations used when computing the transport wind for a sampling step that includes gradual rise	2	No.
SYMIN	Minimum sigma y for a new puff/slug	1	dimensionless
SZMIN	Minimum sigma z for a new puff/slug	1	dimensionless
SVMIN	Default minimum turbulence velocities sigma-v for each stability class for Land	0.5	m/s
SVMIN	Default minimum turbulence velocities sigma-v for each stability class for Water	0.37	m/s
SWMIN	Default minimum turbulence velocities sigma-w for stability class A for Land and Water	0.2	m/s
SWMIN	Default minimum turbulence velocities sigma-w for stability class B for Land and Water	0.12	m/s

SWMIN	Default minimum turbulence velocities sigma-w for stability class C for Land and Water	0.08	m/s
SWMIN	Default minimum turbulence velocities sigma-w for stability class D for Land and Water	0.06	m/s
SWMIN	Default minimum turbulence velocities sigma-w for stability class E for Land and Water	0.03	m/s
SWMIN	Default minimum turbulence velocities sigma-w for stability class F for Land and Water	0.01	m/s
CDIV	Divergence criterion for dw/dz across puff used to initiate adjustment for horizontal convergence. Partial adjustment starts at CDIV(1), and full adjustment is reached at CDIV(2)	0, 0	1/s
WSCALM	Minimum wind speed allowed for non-calm conditions	0.5	m/s
XMAXZ1	Maximum mixing height	3000	m
XMINZ1	Minimum mixing height	50	m
WSCAT	Default wind speed classes – Upper bound 1	1.54	m/s
WSCAT	Default wind speed classes – Upper bound 2	3.09	m/s
WSCAT	Default wind speed classes – Upper bound 3	5.14	m/s
WSCAT	Default wind speed classes – Upper bound 4	8.23	m/s

WSCAT	Default wind speed classes – Upper bound 5	10.8	m/s
PLX0	Default wind speed profile power-law exponents for stability A	0.07	dimensionless
PLX0	Default wind speed profile power-law exponents for stability B	0.07	dimensionless
PLX0	Default wind speed profile power-law exponents for stability C	0.10	dimensionless
PLX0	Default wind speed profile power-law exponents for stability D	0.15	dimensionless
PLX0	Default wind speed profile power-law exponents for stability E	0.35	dimensionless
PLX0	Default wind speed profile power-law exponents for stability F	0.55	dimensionless
PPC	Default plume path coefficients for stability class A (used when MCTADJ=3)	0.5	dimensionless
PPC	Default plume path coefficients for stability class B (used when MCTADJ=3)	0.5	dimensionless
PPC	Default plume path coefficients for stability class C (used when MCTADJ=3)	0.5	dimensionless
PPC	Default plume path coefficients for stability class D (used when MCTADJ=3)	0.5	dimensionless
PPC	Default plume path coefficients for stability class E (used when MCTADJ=3)	0.35	dimensionless

PPC	Default plume path coefficients for stability class F (used when MCTADJ=3)	0.35	dimensionless
SL2PF	Slug-to-puff transition criterion factor equal to sigma-y/length of slug	10	dimensionless
NSPLIT	Number of puffs that results every time a puff is split (nsplit=2 means that 1 puff splits into 2)	3	No.
IRESPLIT	Time(s) of day when split puffs are eligible to be split once again; this is typically set once per day	17 th	hr
ZISPLIT	Split is allowed only if last hour's mixing height (m) exceeds a minimum value	100	m
ROLDMAX	Split is allowed only if ratio of last hour's mixing ht to the maximum mixing ht experienced by the puff is less than a maximum value	0.25	dimensionless
NSPLITH	Number of puffs that result every time a puff is split (nsplith=5 means that 1 puff splits into 5)	5	No.
SYSPLITH	Minimum sigma-y (Grid Cells Units) of puff before it may be split	1	No.
SHSPLITH	Minimum puff elongation rate (SYSPLITH/hr) due to wind shear, before it may be split	2	No./hr
CNSPLITH	Minimum concentration of each species in puff before it may be split	1.0E-07	g/m ³
EPSSLUG	Fractional convergence criterion for numerical SLUG sampling integration	1.0E-04	dimensionless

EPSAREA	Fractional convergence criterion for numerical AREA source integration	1.0E-06	dimensionless
DRISE	Trajectory step-length used for numerical rise integration	1	m

CALPUFF requires several types of input data such as source emissions and locations (Source parameters), meteorological data, land use data, and receptor data for simulation of impact of emissions sources on ambient air. These input parameters are discussed in following sections.

3.2 *Source Parameters*

The emission points to be considered under various scenarios in the air dispersion modeling have been listed in Section 2.2. All of the proposed emission points are point sources with identified stacks venting the emissions to the atmosphere. This section describes the parameters required in CALPUFF for point sources and the procedure for estimating the parameters.

Emission Rates: Emission rates will be calculated using manufacturer's data where available. If not available, then USEPA's AP-42 emission factor database will be used. For SO₂, a mass balance will be used considering all sulfur bearing compounds converted 100% to SO₂. The details of the calculations will be explained in the final report. Table 3-3 summarizes the emission rates of modeled pollutants to be considered in the analyses. The same emission rates were used in the Class II PSD increment and NAAQS analyses.

For both gas turbines and flares, the short-term and annual average emission rates are the same and at full capacity of the units.

**Table 3-3
Modeled Emission Rates**

Pollutant	Averaging Period	Enclosed Flares¹ (lb/hr)	Open Flares² (lb/hr)	LFG Turbines³ (lb/hr)
NOx	Annual	5.4	6.7	31.1
SO ₂ Interim	3-Hour	72.9	80.2	-
	24-Hour	72.9	80.2	-
	Annual	72.9	80.2	-
SO ₂ BACT	3-Hour	12.1	13.4	16.2
	24-Hour	12.1	13.4	16.2
	Annual	12.1	13.4	16.2
PM ₁₀	24-Hour	1.4	1.5	2.2
	Annual	1.4	1.5	2.2

Notes:

- 1: For interim and alternative BACT scenarios only
- 2: For routine and alternative BACT scenario only
- 3: For Routine BACT scenario only

Stack Gas Parameters: Stack gas parameters included: i) stack gas exit temperature, and ii) stack gas exit velocity. These are discussed separately.

Stack gas exit temperatures for the enclosed flares and the turbines will be obtained from manufacturer's information. For open flares, stack gas exit temperature can not be measured and is a function of the degree and rate of entrainment of ambient air in the flared gases. Ohio Environmental Protection Agency (OEPA) and Texas Commission on Environmental Quality (TCEQ) have guidelines for estimating stack gas temperature and flow rate from open industrial flares. Upon review, Shaw Environmental, Inc. determined that the OEPA guidelines are more conservative and therefore it will be used for the estimation of stack gas temperature. A copy of the guideline (Engineering Guide #69) is included in Appendix A. The guide assumes stack gas temperature of 1273 degrees Kelvin for industrial flares.

Stack exit velocities for enclosed flares will be obtained from stack gas flow rates and stack diameters. Stack gas flowrate for enclosed flares will be obtained from combustion calculations of the manufacturer's maximum landfill gas flow rate through the flares and approximately at 230% excess air conditions, typical of enclosed landfill gas flares. Stack gas velocity for turbines will be obtained from manufacturer's data. As per OEPA guide on flares described above, stack exit velocity of all open flares will be considered as 20 meters per second (m/s).

Physical Stack Parameters: Physical stack parameters include: i) stack height, stack diameter; and stack location (coordinates). For enclosed flares and combustion turbines, the estimated stack height and diameter will be obtained from manufacturer's information.

The physical stack diameter and height will not be considered (for air dispersion modeling purposes) for the open flares, as per the OEPA guide. Instead virtual stack diameter and stack height will be calculated to be used for air dispersion modeling purposes. The virtual stack diameter will be calculated from a buoyant flux based on a default stack temperature of 1273 degrees Kelvin (K), a stack gas flow rate based on the buoyant flux, and the stack diameter based on the OEPA-Guidance default stack exit velocity of 20 m/s. The virtual stack height will be calculated as a function of total heat release in combustion of the gas. Details of the calculations will be included in the report.

Stack coordinates for all flares and turbines will be obtained from equipment layout and a digitized map of the facility. The stack locations will be converted to NAD83 UTM coordinates for consistency with receptor coordinates.

Table 3-4 shows the stack parameters to be used in the air dispersion modeling analysis.

Table 3-4: Modeled Stack Parameters

Control Device ID	Description	Location (UTM) Easting (m)	Location (UTM) Northing (m)	Estimated Stack Height (ft)	Stack Exit Gas Temperature (F)	Stack Velocity (ft/s)	Stack Diameter (ft)
CD001	Existing Enclosed Flare	530433.1	3023829.9	45	1,400	38.084	10.000
CD002	Existing Enclosed Flare	530433.1	3023836.0	45	1,400	38.084	10.000
CD003	Utility Flare 1 (backup)	530433.1	3023842.1	62.85	1,831.73	65.616	5.729
CD004	Utility Flare 2 (odor)	530433.1	3023848.2	62.85	1,831.73	65.616	5.729
CD005	Utility Flare 3	530433.1	3023854.3	62.85	1,831.73	65.616	5.729
CD006	Utility Flare 4	530433.1	3023860.4	62.85	1,831.73	65.616	5.729
CD007	Utility Flare 5	530433.1	3023866.5	62.85	1,831.73	65.616	5.729
CD008	Utility Flare 6	530433.1	3023872.6	62.85	1,831.73	65.616	5.729
CD009	Utility Flare 7	530433.1	3023878.7	62.85	1,831.73	65.616	5.729
CD010	Utility Flare 8	530433.1	3023884.8	62.85	1,831.73	65.616	5.729
CD011	Turbine 1	530470.5	3023713.2	50	894	58.681	8.371
CD012	Turbine 2	530470.5	3023719.3	50	894	58.681	8.371
CD013	Turbine 3	530470.5	3023725.4	50	894	58.681	8.371
CD014	Turbine 4	530470.5	3023731.5	50	894	58.681	8.371
CD015	Turbine 5	530470.5	3023737.6	50	894	58.681	8.371
CD016	Turbine 6	530470.5	3023743.7	50	894	58.681	8.371
CD017	Turbine 7	530470.5	3023749.8	50	894	58.681	8.371
CD018	Utility Flare 9 (replaces enclosed flare)	530433.1	3023829.9	62.85	1,831.73	65.616	5.729
CD019	Utility Flare 10 (replaces enclosed flare)	530433.1	3023836.0	62.85	1,831.73	65.616	5.729

3.3 Load Analysis

For many combustion turbines the operating load has impact on the emissions and also on the stack gas parameters. As such, the ambient impact might vary at different loads. This analysis is relevant for the proposed combustion turbines, in which emission rates for NO_x varies at varying loads. The flares are considered to operate always at full load as per common practice in landfills and therefore the flares are not included in load analysis.

The analysis was conducted at 100%, 75%, and 50% of the operating load for a single turbine. Estimated stack gas flow parameters and emission rates were obtained from the manufacturers. With concurrence from FLDEP, the SCREEN3 model (version 96043) was used in this screening level analysis.

The results of the analysis are shown in Table 3-5. The NO_x impacts were highest at full load. Therefore this operating load will be considered for NO_x in subsequent air dispersion modeling analysis.

**Table 3-5
Load Analysis for LFG Turbines**

Pollutant	Averaging Period	100% Load (ug/m³)	75% Load (ug/m³)	50% Load (ug/m³)
NO _x	1-hour	28.73	18.17	12.99

3.4 Building Downwash Analysis

Building downwash analysis will not be considered in the long range transport modeling because the national parks were approximately 174 km from the facility sources. At this distance, there would be no appreciable impact of building downwash.

3.5 Meteorological Data

Meteorological data in MM5 format has been processed by FDEP with CALMET (version 5.8) to develop the meteorological data set for CALPUFF. The data processed data has been sent to Shaw for direct use with the CALPUFF. The data are for years 2001, 2002, and 2003. FLAG guidance requires that the modeling domain extend at least 50 km upwind of the emission source and 50 km in all sides of the Class I area being modeled.

Based on information from FDEP, the MM5 data was developed for 4 km grid areas and with 10 vertical layers as required by FLAG for refined analysis.

3.6 Receptor Layout

The NPS has predetermined locations of receptors in each Class I area. The receptors for the Everglades NP were obtained from the NPS website and are shown in Figure 3-1. These receptors will be used in the analysis. Since no receptors were available for Biscayne Bay NP and Big Cypress National Preserve in the NPS website, receptor grids covering these areas were developed and are shown in Figure 3-2 and Figure 3-3, respectively.

3.7 Background Concentrations of Ammonia and Ozone

CALPUFF/CALPOST requires background concentration for ammonia and ozone to use the chemical transformation algorithms. The background concentrations to be used are as follows:

Ammonia Background Concentration: There was no ammonia monitoring station in the Everglades NP, Biscayne Bay NP, or Big Cypress National Preserve. FLAG recommends use of 0.5 ppb as ammonia background for CALPUFF. This will be used in the analysis.

Ozone Background Concentration: One ozone monitoring station is located in the Everglades NP. Hourly data from the station for 2001, 2002, and 2003 showed an average concentration of 25 ppb, 25 ppb, and 27 ppb, respectively. A conservative value of 30 ppb will be used in the analysis for all years for the Everglades NP, Biscayne Bay NP, and Big Cypress National Preserve. Alternatively, hourly ozone data from the station may be used for the analysis in case this conservative default value shows exceedance of AQRV criteria.

3.8 Background Light Extinction Coefficient

For visibility impact analysis, background light extinction coefficient data is required. The daily background light extinction coefficients will be calculated on an hour by hour basis using hourly relative humidity data from the CALMET and hygroscopic and non-hygroscopic extinctions components of 0.9 Mm^{-1} and 8.5 Mm^{-1} , respectively, as specified in the FLAG 2000 document. Hygroscopic particle growth will be capped at relative humidity of 98% per recent FLAG guidance. Alternatively, the analysis may use the average of background extinction in 20% of clearest days from the IMPROVE 2000-2002 data.

3.9 Ammonia Limiting Method

CALPUFF normally considers that all background ammonia is available to all puffs at the same concentration at all times. While this may be reasonable for a single puff or multiple puffs separated from each other, it is not realistic for overlapping puffs, as is expected in the analysis. Additionally, CALPUFF does not take into consideration the preferential scavenging of

ammonia by sulfates over nitrates. As a result, the nitrate deposition and hence overall visibility impact is overpredicted.

The post-processor POSTUTIL offers a method to correct this situation. An option called the Ammonia Limiting Method (ALM), when switched on, would preferentially scavenge the ammonia for sulfates prior to the nitrate chemistry. This option will be used in the analysis.

3.10 *Relative Humidity Method*

Relative humidity is required at the Class I area to estimate the deposition and visibility impacts. Two methods are currently used in CALPUFF for incorporating relative humidity:

- Method 2, which requires hourly relative humidity data to be used in CALMET
- Method 6, which requires monthly averaged relative humidity data.

As per FLAG guidance, Method 2 will be used in the analysis.

3.11 *Monthly Background Concentrations*

The EPA 2003 monthly background concentrations for Ammonium Sulfate, Ammonium Nitrate, Coarse Particles, Organic Carbon, Soil, and Elemental Carbon will be used in the analysis. The values for the Eastern United States are shown in Table 3-6.

Table 3-6

Monthly Background Concentrations (ug/m³)

Ammonium Sulfate	Ammonium Nitrate	Coarse Particles	Organic Carbon	Soil	Elemental Carbon
0.23	0.10	3.00	1.40	0.50	0.02

3.12 *Rayleigh Scattering Coefficient*

CALPOST uses a default Rayleigh scattering coefficient of 10 Mm⁻¹, which is based on an elevation of 5,000 meters. Rayleigh scattering depends on the density of air, with highest values at sea level (~12 Mm⁻¹) and diminishing with elevation (~12Mm⁻¹ at 8,000 m elevation). The Inter agency Monitoring of Protected Visual Environments (IMPROVE) has developed site specific Rayleigh scattering coefficients for all Class I areas based on site specific pressure and temperature data encompassing 10 to 30 years. For Everglades NP, the adjusted Rayleigh

scattering value of 11.3 Mm^{-1} from this new IMPROVE equation was used in this analysis. No such site specific data was available for the Biscayne Bay NP or Big Cypress National Preserve. However, since Biscayne Bay NP and Big Cypress National Preserve are in the same general area and same general elevation as the Everglades NP, same value will be used.

3.13 Particle Size Fractions

All particulate emissions from the flares and turbines are considered to be filterable fine particulate (PMF) and will be considered accordingly in the CALPUFF model. The individual size fractions will be used if data are available.

4.0 *Compliance Demonstration*

This section describes the analysis to be performed to demonstrate compliance with Class I area impacts.

4.1 *Air Quality*

The Class I significance impact will be compared to the maximum concentration in any of the receptors for the averaging time in all three years of meteorological data (H1H). For Class I PSD Increment analysis, high-second high concentration for short-term averaging times and H1H concentration for annual averaging times will be used to compare with respective increments.

4.2 *Deposition Flux*

Total nitrate (T-NO₃) and total sulfate (T-SO₄) depositions will be estimated at the Everglades NP from the proposed modification. For T-NO₃ deposition, the species will include:

- Particulate ammonium nitrate wet and dry deposition;
- Nitric acid wet and dry deposition;
- NO_x dry deposition; and
- Ammonium sulfate, wet and dry deposition

For T-SO₄ deposition, the species included:

- SO₂ dry and wet deposition; and
- SO₄ dry and wet deposition

The CALPUFF results will be processed in CALPOST and POSTUTIL programs to develop deposition impacts. The impacts will be then compared with the deposition threshold values (DAT) values for the Everglades NP. A DAT is the incremental amount of deposition from proposed modification or source in a Class I area, below which the impacts are considered insignificant. The DAT values are 0.01 kilograms per hectare per year (Kg/ha-yr) for both T-SO₄ and T-NO₃ depositions.

4.3 *Visibility Impact*

The change in visibility is characterized by a change in light extinction coefficient (b_{ext}). The b_{ext} is the attenuation of light per unit distance due to scattering and absorption by gases and

particulates in the atmosphere. The impact of the proposed modification will be measured against the natural or background extinction coefficient to determine the percent change as follows:

$$\% \text{ Change} = (b_{\text{ext-mod}} / b_{\text{ext-background}}) * 100$$

CALPUFF and CALPOST will be used to calculate the extinction at each Class I receptor for each day (24-hour period) due to the proposed modification. The analysis will be conducted as per FLAG 2000 report. Daily background extinction coefficients will be calculated on an hour by hour basis using hourly relative humidity data and hygroscopic and non-hygroscopic extinction coefficients of 0.9 and 8.5 in Mm^{-1} , as per FLAG 200 document. In addition, an elevation-based adjustment will be made to the default Rayleigh scattering coefficient of 11.3 Mm^{-1} .

5.0 Report Format

This section contains the format of the report to be submitted for the Class I area impact analysis. All calculations, back-up data, manufacturer's data will be included in the Appendices. Also, the input/output files of the model runs will be included as an Appendix in a CD.

The format of the report will be as follows:

List of Tables

List of Figures

List of Appendices

- 1.0 Introduction
- 2.0 Background Information
 - 2.1 Description of Site
 - 2.2 Description of Emission Sources
 - 2.3 Elements of Class I Area Analysis
 - 2.4 Existing Environmental Conditions in Everglades National Park
 - 2.5 Existing Environmental Conditions in Biscayne Bay National Park
 - 2.6 Existing Environmental Conditions in Big Cypress National Preserve
- 3.0 Technical Approach and Methodology
 - 3.1 Model Selection and Model Features
 - 3.2 Source Parameters
 - 3.3 Short-term and Long-term Emission Rates
 - 3.4 Load Analysis
 - 3.5 Building Downwash Analysis
 - 3.6 Meteorological Data
 - 3.7 Receptors
 - 3.8 Background Concentrations of Ammonia and Ozone
 - 3.9 Background Light Extinction Coefficients
 - 3.10 Ammonia Limiting method
 - 3.11 Relative Humidity Method
 - 3.12 Rayleigh Scattering Coefficient
 - 3.13 Particulate size fraction
 - 3.14 Summary of CALPUFF Model Settings
- 4.0 Results of Class I Area Impact Analysis
 - 4.1 Class I Area Significance Analysis
 - 4.2 Class I Area PSD Increment Analysis
 - 4.3 Deposition Analysis
 - 4.4 Visibility Impact Analysis
- 5.0 Conclusions

Ohio EPA

Division of Air Pollution Control

Air Quality Modeling and Planning Section

Engineering Guide #69

Air Dispersion Modeling Guidance

2003

The Division of Air Pollution Control has received several questions concerning computer modeling of air pollution sources. This guide is intended to respond to those questions. Below is a list of all of the questions. The rest of the Guide contains the Division's responses. The Division welcomes comments on the application of this Guide and additional questions related to air dispersion modeling.

This document will answer the most commonly asked questions to provide a basis for consistent model application although many other questions require case-specific responses. The answers in this document do not reflect a rule or regulation, are not intended to be treated as a rule or regulation, and are subject to change on a case-by-case basis. The information within is provided so that permitting personnel, regulated entities and the public will have an understanding of the expected outcome of the situations described in this document. If you have additional questions on modeling, or comments on this guide, you should contact the Division of Air Pollution Control (614-644-2270).

.....
Table of Contents

Questions and Answers.....pg 2
APPENDIX A.....pg 29

TABLES

Table 1; Meteorological Assignmentspg 24
Table 2; National Weather Service Anemometer
Heights and Station Numbers.....pg 27
Table 3; Threshold Emission Rates and
Target Concentrationspg 28

Question 1: What specific modeling requirements are incorporated by Ohio EPA in the review of air contaminant sources?

Question 2: What models are to be used?

Question 3: What meteorological data sets are to be used?

Question 4: What modeled emission rate(s) should be used?

Question 4.1: Are fugitive emissions modeled?

Question 4.2: Are there any exceptions to the modeling thresholds for modeling criteria pollutants and toxics contained in Table 3?

Question 4.3: Should sources be modeled that emit pollutants listed in the ACGIH book, do not have a TWA, but do have a Ceiling or STEL?

Question 4.4: Are minor and exempt sources included in the modeling for a project which exceeds the thresholds in Table 3?

Question 4.5: Do you model sources within a building that have no direct vent to the outside or do not have an identified control device for capture, control and release of the emissions from the unit?

Question 5: Is building downwash required for state modeling?

Question 5.1: What building height do I use if the building has a pitched roof?

Question 6: Reserved/Deleted

Question 7: Is there any special guidance for nonstandard point source emissions?

Question 7.1: How do I model rain caps and horizontal releases?

Question 7.2: How do I model flares?

Question 7.3: What special modeling considerations are necessary for modeling combustion turbines?

Question 8: Reserved/Deleted

Question 9: What receptor grids must I use?

Question 10: What are the state significant emission rates which trigger modeling?

Question 10.5: Can a source modification trigger a requirement for modeling even where there is no increase in emission rate?

Question 11: What are the state target concentrations for acceptable incremental impacts?

Question 12: What special requirements exist for sources of fluoride?

Question 13: How do I obtain background values when performing NAAQS analyses in Ohio?

Question 14: What sources do I include in a major source PSD and/or NAAQS analysis?

Question 15: How do I model major sources in nonattainment areas to demonstrate net air quality improvement?

Question 16: Can I use SCREEN to model multiple sources?

Question 17: If multiple pollutants are being emitted, does an individual model run have to be performed for each pollutant?

Question 18: For PSD and non-PSD sources, can facilities be installed if modeling shows that more than ½ the available PSD increment is consumed?

Question 19: What determines whether a locale is rural or urban?

.....

Question 1: What specific modeling requirements are incorporated by Ohio EPA in the review of air contaminant sources?

Answer 1: The following is intended to identify current Ohio EPA, Division of Air Pollution Control requirements for air pollution control modeling applications within Ohio. Where applicable, Ohio EPA is consistent with U.S. EPA guidance. In real world applications, the US EPA Guideline on Air Quality Models and supplementary guidance does not always address detailed problems that confront modelers.

The purpose of air dispersion modeling is to predict pollutant concentrations resulting from a source or group of sources under various meteorological conditions. Modeling is necessary to demonstrate that the subject source or sources will not 1) cause or significantly contribute to a violation of the National Ambient Air Quality Standards (NAAQS); 2) cause ambient concentrations which exceed allowable PSD increments; 3) comply with Ohio EPA's policy of no new source consuming more than one half of the available PSD increment (one half the increment is the effective goal for all new source modeling of criteria pollutants, regardless of the size or location of the new source.); and/or 4) cause ground level concentrations which exceed Ohio EPA's maximum allowable ground level concentration (MAGLC) for toxic air pollutants. For criteria pollutants which do not have identified PSD increments, maximum incremental impact of new source emissions is limited to one quarter of the NAAQS.

The combined emission increases from all of the new or modified sources must be evaluated to determine the maximum incremental impact if the total emissions exceed the amounts indicated in Table 3. For criteria pollutants, the incremental impact cannot exceed one half of any PSD increment or, if no PSD increment exists, one quarter of the NAAQS. There is no requirement to model VOC emissions for incremental impact on ozone concentrations (although specific VOC constituents may require air toxic modeling). **For exceptions to the one half PSD increment policy, see Answer 18.**

New or increased emissions of toxics that exceed the levels identified in Table 3 must be evaluated to determine the maximum incremental impact of these emissions for comparison with the MAGLC as described in Ohio EPA's current procedure for reviewing new sources of air toxics.

Where the permit includes both emission increases and decreases (generally restricted to a contemporaneous 5-year period), the net increase should be modeled. Ohio EPA must approve the 'netting' emissions prior to modeling.

Question 2: What models are to be used?

Answer 2: The specific source/receptor situation dictates the appropriate model for determining ambient concentrations for comparison with NAAQS, PSD increments, short or long term exposure limits, etc. The size and complexity of the source, the

toxicity of the emissions along with other factors will dictate whether a screening model or a refined model is appropriate.

Screening models are generally the first level tools for evaluating air quality impacts. High predicted concentrations from a screening model may indicate the need for further refined modeling. Larger more significant sources and groups of sources will require the application of a refined model.

Sources in areas where terrain elevation is significant relative to the stack height will require evaluation using receptor elevations. Where terrain exceeds the stack height, a complex or intermediate terrain modeling analysis is necessary. This applies to both criteria and toxic pollutants.

Generally, the most recent version of a model is to be used. The most recent model versions of models contained in The Guideline on Air Quality Models (GAQM) can be obtained by accessing the U.S. EPA Support Center for Regulatory Air Models (SCRAM), Technology Transfer Network at <http://www.epa.gov/ttn/scram>. The SCRAM web page also provides model users manuals, ancillary programs, meteorological data and additional model application information. This Engineering Guide and meteorological data for Ohio sources are available on the Ohio EPA DAPC web page located at <http://www.epa.state.oh.us/dapc/aqmp/aqmp.html>

Note: The Guideline on Air Quality Models (Appendix W of 40 CFR Part 51) will be revised. AERMOD has been identified as the replacement for the ISC models. Federal guidance has indicated that both AERMOD and ISC will be acceptable for no more than one year after the final rule is published. At which time ISC will no longer be acceptable for PSD and SIP related modeling. Ohio EPA will continue to accept ISC for state-only permits and modeling projects until further notice.

Screening models:

Note: There is currently no screening version of AERMOD to replace SCREEN3. Until further notice, SCREEN3 will still be accepted by Ohio EPA for state-only permit modeling.

The current recommended model for screening point or area sources in simple terrain is the most recent version of SCREEN3 (or its successor), for criteria pollutants or for applications where maximum ambient concentrations of neutral buoyancy pollutants are desired. A fundamental assumption for pollutants being modeled with traditional Gaussian models is that the concentration of the pollutant in the plume will not make the plume disperse or diffuse differently than air.

Applications requiring an evaluation of emergency release scenarios or sources emitting 'light' or 'heavy' plumes may use one of the commercially available toxic

release models to determine if ambient impacts exceed the applicable MAGLC. Most routine releases, even of heavy compounds, will have a density close to that of air due to high dilution.

Point sources with stacks less than good engineering height (discussed below) must be evaluated for downwash impacts using the SCREEN3 or SCREEN3C model (or their successors).

Initial screening estimates of source impacts involving intermediate or complex terrain should utilize SCREEN3 or CTSCREEN (or their successors). SCREEN3 is available as an interactive program by itself or within the TSCREEN model set.

The output from these models identifies short term (1-hour) maximum impacts. The following are the conversion factors to be used to convert these short term estimates to the averaging time of concern. Separate conversion factors have been recommended by U.S. EPA for terrain below stack tip (simple terrain) and terrain above stack tip (complex terrain).

Conversion Factors

Model output	Desired Averaging Period						
	1-hr	3-hr	8-hr	24-hr	month	qtr	ann
Simple 1-hr:	1.000	0.900	0.700	0.400	0.180	0.130	0.080
Complex 1-hr	1.000	0.700	0.500	0.150		0.060	0.030

Additional guidance on the use of SCREEN and TSCREEN is provided in Appendix A of this document.

Complex and intermediate terrain screening for state-only permit requirements can also be performed using ISC3 with five years of NWS data.

Refined models:

The most commonly used refined models for point, area and volume sources involving simple, intermediate and complex terrain are the most recent versions of ISCST3 and ISCLT3 (or their successors) using representative meteorological data in the regulatory default modes. Several commercial versions of these models have been granted model equivalency by U.S. EPA and are therefore also acceptable. For refined toxic analyses, the same procedures used for criteria pollutants are used to determine ambient concentrations. There are currently no requirements for deposition calculations. Modeling involving pollutant transformations (ozone, nitrates, sulfates) is not generally required for new or modified sources and is not addressed in this guide.

Question 3: What meteorological data sets are to be used?

Answer 3: Short Term: ISC Data Sets: Hourly surface observations are combined with twice-daily mixing height measurement to create a RAMMET meteorological input file. RAMMET data files can be created using on-site tower measurements or off-site National Weather Service (NWS) surface data sets.

If the modeling is for NAAQS or PSD analyses, at least one year of on-site or the most recent available five years of representative off-site NWS data are required. If the source of concern is located in intermediate or complex terrain, U.S. EPA believes that NWS data are not representative for the above stack portion of the analysis and are therefore not acceptable. For state-only modeling requirements, 5 years of NWS data are considered acceptable for use in a conservative screening analysis.

The most recent five-year off-site NWS data sets currently available from Ohio EPA are for the period 1987-1991. These data are acceptable. Later NWS data are also acceptable but not required. Off-site NWS data sets are assigned by county. Table 1 identifies the appropriate data set for each county in Ohio.

Certain southeastern counties of the state have been assigned Parkersburg/Huntington RAMMET and STAR data for modeling. For counties assigned 'Parkersburg' surface data, 1973-1977 data are the most recent available. This surface site is the most representative available for modeling in this region of Ohio and the older data set is considered more representative for these counties than more recent Huntington or Pittsburgh data.

NOTE: While the State of Ohio accepts NWS data for use in modeling in both simple and complex terrain for state-only modeling requirements, U.S. EPA has a more restrictive interpretation of 'representative' meteorological data when modeling impacts at receptors with elevations above the stack tip. For this and other reasons, it is important when preparing to model major PSD or nonattainment sources, that a protocol is developed and approved to assure that acceptable model calculations will be obtained for each source/receptor relationship.

AERMOD Data Sets: On-site or NWS surface data sets are combined with local surface characteristics and upper air observations within the AERMET preprocessor program to create the needed modeling meteorological data sets for AERMOD. The latest five-year data sets for use in Ohio will be provided on the Ohio EPA web page at <http://www.epa.state.oh.us/dapc/aqmp/aqmp.html> after Appendix W is finalized and final guidance is issued by U.S. EPA.

Long term: Long term (e.g., monthly, quarterly, annually) meteorological data sets are developed from short term on-site or off-site (NWS) surface data sets. These long term STAR (STability ARray) data sets are necessary to run ISCLT3 or other ISCLT3-based

long term models.

ISCST3 and AERMOD can also be used for long term modeling periods by modeling specific blocks of days and selecting appropriate n-day average concentrations.

Question 4: What modeled emission rate(s) should be used?

Answer 4: Tables 9-1 and 9-2 in the Guideline on Air Quality Models (Appendix W of 40 CFR Part 51) identify the various emission rates to be used in modeling a source. In general, the short term maximum potential (allowable) emission rate is used in the evaluation of a short term standard. For an existing source, a representative long term actual emission rate can be used to evaluate a longer term (quarterly or annual) standard. An annual permit restriction can also be used to develop a long term average emission rate to be used in evaluating a long term standard for a new source.

For state permit modeling, including Ohio air toxics modeling, the peak short term increase which the permit will allow is the emission rate to be modeled to determine the peak ambient impact this permit action will allow. This could involve the combined peak impact of several sources if there are several sources included in the same project.

For a federal netting or synthetic minor permit, the difference between existing actuals emissions and permit allowable emissions, as determined in the netting calculation, is modeled for comparison to the Ohio acceptable incremental impacts. For state-only netting modeling evaluations, the allowable to allowable difference is usually acceptable. For PSD or federal netting, though, modeled emissions should be consistent with the netting evaluation performed for the permit.

For a modification which involves an emission increase only, the net change allowed by the permit is evaluated. For PSD and other federal analyses, the net change is the difference between the existing actual emissions and the new potential allowable emissions. For state-only review, modeling the difference in allowables is usually acceptable.

For a modification involving a change in stack parameters which could increase the ambient impact due to the source(s), the emissions affected by the modification (potential allowable) are modeled to determine if the impact of the modification is below the Ohio acceptable incremental impacts. If necessary, the present (before modification) emissions can be modeled as negatives in a refined analysis to determine the net impact of the permitted modification for comparison to the Ohio acceptable incremental impacts.

Like-kind replacements would not need modeling if all emissions parameters remain the same since there would be no increase in impact due to the permit action. If, however, the replacement involves the use of a shorter stack, lower temperatures, etc., the

replacement may cause an increased peak impact which would need evaluation. As noted above, if the replacement, when viewed alone, exceeds the Ohio acceptable incremental impacts as identified in Table 3, the source being replaced can be modeled with a negative emission rate in a refined modeling analysis to determine the net peak impact for comparison to the Ohio acceptable incremental impacts. Also, see Question 14 for additional information on emission inventories.

Question 4.1: Are fugitive emissions modeled?

Answer 4.1: Major new source PSD and Nonattainment Review includes all significant sources, including fugitive sources such as storage piles and roadways.

In minor source state permit modeling, though, only the boiler or process source criteria and toxic emissions increases (both controlled and fugitive) are to be modeled. Non-process fugitive sources such as roadways and parking lots, material storage and material transfer operations are not modeled. Grinding, crushing, mixing and screening operations are considered processes and should be modeled. An evaluation of all project emissions may be required in a state analysis if circumstances warrant.

Question 4.2: Are there any exceptions to the modeling thresholds for modeling criteria pollutants and toxics contained in Table 3?

Answer 4.2: There are several new source emissions scenarios which Ohio EPA has historically not reviewed for state-only permits. These scenarios generally involve fugitive emissions from parking lots, roadways, material handling and storage piles. These scenarios usually represent situations where modeling results often indicate potential problems due to unreliable emission factors and/or unusual or extreme source configurations. Field experience with these sources, though, indicates that normal operating practices and compliance with required controls result in acceptable ambient impacts as demonstrated by ambient monitoring, field measurements of visible emissions or a lack of verified complaints by local citizens.

Therefore, the following list of source/pollutant scenarios will not be required to perform an air quality analysis in support of a state-only permit **unless factors such as source size, tons of emissions, particle size, pre-existing concerns or proximity to other sources or citizen populations indicate that a modeling review is warranted:**

- Toxic or criteria pollutants from parking lots
- Toxic or criteria pollutants from storage piles
- Toxic or criteria pollutants from storage tanks
- Toxic or criteria pollutants from transfer operations
- Toxic or criteria pollutants from grain silos or dryers

Toxic or criteria pollutants from emergency generators
Toxic or criteria pollutants from gasoline dispensing

In addition, the following pollutants will be treated as PM but not as a toxic for modeling purposes:

Wood dust
Sand
Glass dust
Coal dust
Silica
Grain dust

Source/Toxic Pollutant combinations subject to a MACT, NESHAP or an NSPS that would restrict the amount of that pollutant that could be released are not subject to toxics modeling. Toxics modeling is also not required for pollutants subject to a NAAQS (e.g., lead).

Question 4.3: Should sources be modeled that emit pollutants listed in the ACGIH book, do not have a TWA, but do have a Ceiling or STEL?

Answer 4.3: Yes, pollutants not having a listed TWA are addressed by multiplying the Ceiling or STEL by 0.737 and then following the procedures in 'Option A' to develop a MAGLC.

Question 4.4: Are minor and exempt sources included in the modeling for a project which exceeds the thresholds in Table 3?

Answer 4.4: All sources or units contained in the permits that make up a project are initially considered significant with respect to the potential impact due to the project. Many small sources, while individually insignificant, could combine to cause or contribute to an ambient problem. Smaller sources can be removed from the modeling analysis if it can be demonstrated that their emissions are insignificant relative to the rest of the project.

Question 4.5: Do you model sources within a building that have no direct vent to the outside or do not have an identified control device for capture, control and release of the emissions from the unit?

Answer 4.5: Sources can be located within an enclosure or building with no obvious control and/or vent moving the emissions to the outside. It must be assumed that all

emissions coming from the device are either captured and controlled or are escaping to ambient air. If they are not being captured and controlled (with the cleaned air being reintroduced to the work area), the emissions must be escaping the building and the modeler must determine how the emissions are being removed from the building or enclosure to the ambient air. The emission rate leaving the building or enclosure is assumed to be the same as the emission rate from the source(s). Any credit for some portion of the emissions being retained in the building due to “building capture” must be supportable and will be evaluated on a case-by-case basis.

Often the emissions are removed by the building ventilation system. In other situations, the only exchange between indoor and outdoor air occurs through open doors and windows. In any event, the modeler must identify the egress point(s) and characterize the releases as one of the available modeling release scenarios (i.e., point, area or volume). If best engineering judgement justifies assigning a fraction of the total emissions through specific egress points, the individual points can be modeled with their assigned emission rates. When using a single source screening model, the individual modeled peaks are then added together.

If it is unclear which potential egress point the emissions are actually venting through, the worst case egress point is assumed. If it is not clear which egress point is worst case, each scenario should be tested.

Question 5: Is building downwash required for state modeling?

Answer 5: Any stack source file must include building dimension data if the stack is not at or above good engineering practice (GEP) stack height. GEP is determined by evaluating all nearby structures using the formula $GEP = H + 1.5L$ where H is the height of the structure and L is the lesser of the height or projected width of the structure. The GEP height is the highest height calculated for any nearby structure (a structure is ‘nearby’ if it is within five times the lesser of its height or width from the stack). If direction specific building dimensions (discussed below) are not calculated, the most conservative dimensions should be used for all directions. The most conservative building dimensions are usually associated with the height and diagonal width of the tallest nearby building.

Direction specific building dimensions may be determined for 36 wind directions for ISCST or AERMOD and 16 wind directions for ISCLT. This allows the model to include the effects of the critical structure for each wind direction. Direction specific building dimensions are calculated using facility plot plans and manually determining the dominant structure dimensions for each wind direction for each stack. Alternatively, the BPIP program provided by the U.S. EPA as well as several commercial software packages are available which will calculate the dimensions for each wind direction from a single building or group of buildings for each stack.

Buildings with multiple segments can be viewed as multiple buildings. For example, a predominantly flat one story building is interrupted by a three-story tower, the flat, one story building is evaluated and the 'four story' building (1 + 3), with lateral dimensions of the tower is also evaluated.

Building dimensions are not contained in state or federal emissions data bases. These data need to be obtained from facility personnel if sources at that facility are subject to building downwash. Distant background sources might be modeled without downwash with Ohio EPA permission since this would most likely maximize those sources' impact in the study area and therefore be 'conservative'.

Question 5.1: What building height do I use if the building has a pitched roof?

Answer 5.1: Pitched roofs present a nonstandard modeling scenario. The horizontal dimensions at the peak are reduced to a single line. A conservative approach is to assume that the entire horizontal dimensions are covered by a flat roof at the elevation of the peak of the pitched roof. An acceptable alternative is to assume a building height one half the distance up the pitched roof and the corresponding horizontal dimensions below that 'roof' (i.e., one horizontal dimension would also be halved).

Question 7: Is there any special guidance for nonstandard point source emissions?

Answer 7: Nonstandard source emissions are not specifically addressed in the above screening or refined models. For example, if emissions do not exit the stack in an upward (vertical) direction, alternative characterizations of the source should be developed to more accurately represent the release point. If a 'point source' is still assumed, even though the exit velocity is blocked or diverted sideways or downward (such as in a rain cap, discussed below), an exit velocity of 0.001 m/s should be input to the model so that a fictitious upward momentum is not credited to that source.

If the temperature of the release is near ambient, a characterization as an area or volume source might be appropriate. If temperature is significant, a virtual stack might be created to represent the emission point. Alternative characterizations should be discussed with Ohio EPA staff prior to modeling.

Question 7.1: How do I model rain caps and horizontal releases?

Answer 7.1: U.S. EPA has provided a specific solution to address hot stack plumes that are interrupted by a rain cap or which are released horizontally. U.S. EPA requires that these sources reduce their stack exit velocity to 0.001 m/s.

While it would be conservative to simply reduce the velocity, the source would lose the effect of the buoyancy that the volume of hot gas would normally have. The Ohio EPA recommended adjustment provides for retention of the buoyancy while addressing the impediment to the vertical momentum of the release. The procedure is as follows (stack parameters' units are assumed to be in metric units):

1) The stack exit velocity (V_s) is set equal to 0.001 m/s (V_s')

2) Stack diameter (d_s) is adjusted using the equation

$$d_s' = 31.6 * d_s * (V_s)^{0.5}$$

(Where V_s is the actual stack exit velocity, NOT 0.001 m/s)

3) Use V_s' and d_s' in the model

The results of this approach can create an extremely large modeled stack diameter. Receptors should not be placed within the calculated diameter, d_s' .

Question 7.2: How do I model flares?

Answer 7.2: For screening purposes, the flare option in SCREEN3 or TSCREEN is acceptable. For refined modeling, it is necessary to compute equivalent emission parameters, i.e., adjusted values of temperature and stack height and diameter. Several methods appear in the literature, none of which seems to be universally accepted. Ohio EPA/DAPC has used the following procedure, which is believed to be consistent with SCREEN3:

- 1) compute the adjustment to stack height as a function of heat release Q in MMBtu/hr:

$$H_{\text{equiv.}} = H_{\text{actual}} + 0.944(Q)^{0.478} \quad (a)$$

Where H has units of meters;

- 2) assume temperature of 1273 deg. K;
- 3) assume exit velocity of 20 meters/sec;
- 4) assume the following buoyant flux:

$$F_b = 1.162(Q)$$

- 5) back-calculate the stack diameter that corresponds to the above assumed parameters. Recall the definition of buoyant flux:

$$F_b = 3.12(V)(T_{\text{stack}} - T_{\text{ambient}})/T_{\text{stack}}$$

Where V is the volumetric flow rate, actual m³/sec.

Substituting for F_b and solving for the equivalent stack diameter d_{equiv.}:

$$d_{\text{equiv.}} = 0.1755(Q)^{0.5}$$

This method pertains to the “typical” flare, and will be more or less accurate depending on various parameters of the flare in question, such as heat content and molecular weight of the fuel, velocity of the uncombusted fuel/air mixture, presence of steam for soot control, etc. Hence, this method may not be applicable to every situation, and the applicant may submit his own properly documented method.

(a) Beychok, M., 1979. Fundamentals of Stack Gas Dispersion, Irvine, CA.

Question 7.3: What special modeling considerations are necessary for modeling combustion turbines?

Answer 7.3: Combustion turbines are unique in that stack temperatures and flow rates, as well as emission rates, are dependant on ambient conditions, especially ambient temperature. Determining a worst case operating scenario resulting in peak source impacts involves evaluating the source at multiple loads (50%, 75% and 100%) as well as average and extreme ambient temperatures. Three general approaches are normally followed to establish the worst case operating scenario. The approaches described below address a PSD application.

Approach 1: Each scenario is modeled using SCREEN3. If each scenario results in insignificant impact, then the demonstration is complete. If one or more scenarios result in significant impact, the worst case scenario is carried forward into the PSD and NAAQS analyses using ISC or AERMOD. If there is no clear cut worst case scenario, multiple scenarios may need to be carried forward into the subsequent comprehensive analyses. All other things being equal, it is preferable to move forward with a 100% load scenario rather than a reduced load scenario.

Approach 2: Each scenario is modeled with ISC or AERMOD using the latest year of meteorology. The worst case scenario(s) is then run with five years of meteorology to determine if the proposed project will have a significant impact. If there is a significant impact, then the worst case scenarios are carried forward into the PSD and NAAQS analyses.

Approach 3: Worst case emission rates and stack parameters from all scenarios are used to estimate a worst case impact. This virtual worst case stack can be used through all phases of the analysis.

The same approaches can be followed for state-only (e.g., synthetic minors) modeling, with the only goal to be achieved being the Ohio Acceptable Incremental Impacts.

Question 9:What receptor grids must I use?

Answer 9: Sufficient receptors are necessary in the vicinity of projected maximum concentrations to assure that the peak concentration(s) has been found. For most applications, the spacing should be 100 meters at the 'hotspot', determined from the preliminary modeling results (either ISC, AERMOD or a screening model), out to a distance sufficient to assure that the maximum concentration has been found. Additional receptors should also be placed in areas of special concern (e.g., areas of source interaction and areas of significant terrain). It is also important that the extent of the grid covers the entire area of significant impact from the proposed project.

Receptor elevations are required unless a demonstration that the study area is flat is made. The absence of terrain above stack height is not sufficient to ignore terrain heights. 'Simple' terrain does not mean 'flat' terrain. Topographical data indicating no significant terrain features in the expected significant impact area of the source(s) or indicating flat but gently sloping terrain could justify not including terrain heights for the receptors in that study area.

Receptor elevation information as well as source and receptor location information can be derived from information contained on United States Geological Service topographical maps as well as from internet sources such as www.topozone.com. Information is also available from Digital Elevation Model (DEM) files which are also available from various host sites on the internet. DEM files are available free of charge at <http://data.geocomm.com/dem/>.

AERMOD receptor grids must be exclusively developed using the AERMAP preprocessor using DEM data. Receptor information must contain calculated information concerning the relative height of the nearby terrain (receptor height scales) in addition to the location and elevation of the receptor.

Question 10: What are the state significant emission rates which trigger modeling?

Answer 10: A comprehensive list of emission rates which trigger state and federal modeling requirements is contained in Table 3 under the heading "Ohio Modeling Significant Emission Rates." The emissions increase which will be allowed by this permit action (potential allowable increase) are compared to these levels.

Question 10.5: Can a source modification trigger a requirement for modeling even where there is no increase in emission rate?

Answer 10.5: OAC 3745-31-01(VV)(1)(b) defines “modification” to include “Any physical change in, or change in the method of operation of any significant air contaminant source that, for the specific air contaminant . . . for which the source is classified as significant, results in an increase in the ambient air quality impact . . . greater than certain values specified in the rule. Thus, if the source is “significant” (as defined in OAC 3745-31-01(RRR)) and the proposed incremental impact at any receptor exceeds the specified value (listed under the “3745-31-01(VV)(1)(b)” heading in Table 3) then the change is a modification requiring a permit-to-install, notwithstanding the fact that it may entail no increase in emissions.

It should be kept in mind that the provisions for OAC 3745-31-01(VV)(1)(b) were promulgated for the sole purpose of ensuring that the ambient air quality standards are protected. If this provision is triggered, BAT is not required. Also, this provision is not required under any federal regulation and has not been submitted to U.S. EPA for approval as part of the SIP.

It should also be noted that the concentrations in (VV) are only trigger concentrations and are not maximum allowable impacts. The ambient air quality standards and, if applicable, the PSD increments would be the limiting factor.

An example is a coal-fired boiler where a scrubber is proposed to be installed to remove sulfur dioxide. Even though the actual and allowable emissions of NO_x might not increase, the reduced stack temperature and velocity associated with the scrubber could result in an increase of ambient concentration at some receptor exceeding the 15 ug/m³ limit under (VV)(1)(b), thereby triggering the requirement to obtain a PTI before beginning construction. Another example is any reduction of stack height. For either example the need for modeling is apparent, to resolve the PTI question. A screening model may be used, or if a refined model is selected, the controlling concentration will be the high-high increase of concentration anywhere on the receptor grid, for the relevant averaging period, using five years of off-site or one-year of on-site meteorological data.

Question 11: What are the state target concentrations for acceptable incremental impacts?

Answer 11: Table 3 also contains a listing of national ambient air quality standards and PSD increments as well as state target ambient concentrations for criteria pollutants and specific toxic emissions subject to the state air toxic policy. The state target concentrations for criteria and toxic pollutants listed under the heading “Ohio Acceptable Incremental Impact” represent the acceptable incremental impact of the new emissions which are the subject of a state permit requirement. The Ohio

significant impacts under OAC 3745-31-01 (VV)(1)(b) identify modeled impact levels which trigger permit to install requirements for a source modification (including stack height changes).

Question 12: What special requirements exist for sources of fluoride?

Answer 12: The potential for secondary impacts due to fluorides is greater than the probability for primary human health effects. Therefore, there may be observable impacts and actual complaints of damage to plants and property when the MAGLC has not been exceeded.

The approach to follow when evaluating the secondary impacts due to fluorides is as follows. The secondary 'target' is 0.5 ug/m³ as a 30-day average. The screening approach is to model a 1-hour concentration using SCREEN and convert it to a 'monthly' average using the 0.18 conversion. Monthly averages can also be modeled directly using ISCST or ISCLT or AERMOD. The incremental impact of the new emissions is modeled.

This 'secondary' approach would also be appropriate for any other pollutants where it is determined that there may be significant non health related impacts at levels below the MAGLC.

Question 13: How do I obtain background values when performing NAAQS analyses in Ohio?

Answer 13: Modeling analyses which must estimate total concentrations of a pollutant (e.g., PSD analyses which evaluate the NAAQS) must account for those sources which are either too small or too distant to be included in the modeling analysis. This is accomplished by adding a background value to the modeled concentrations.

A separate background value is needed for each NAAQS pollutant and for each NAAQS averaging time. Actual monitored data for the most recent year, from a representative monitoring site(s) are the basis for acceptable background values. Ideally, the monitor should not be impacted by any major sources or any local smaller sources. If an unimpacted monitor is available, the second highest value for each short-term period would represent the short term backgrounds. The annual average is the annual background. The highest quarterly average would be used for lead.

If an unimpacted monitor is not available, nonimpacted values from monitors which are near a limited number of sources and which have nonimpacted sectors (no upwind sources) can be used to develop background values. **Unadjusted impacted monitor values can also be used as a conservative background.**

A nonimpacted value is a monitored value measured during a period when the wind was not blowing from a 90-degree sector centered on a line between the monitor and the potentially impacting source. For a 3-hour value, no winds should be from the impacting sectors. For 24-hour values, no more than two hours should have winds from the impacting sectors. For short term backgrounds, the second highest nonimpacted value is chosen as a fixed background. Long term background values are the average of the nonimpacted values for the specific averaging time period.

Question 14: What sources do I include in a major source PSD and/or NAAQS analysis?

Answer 14: Major Source NAAQS Analysis: All sources within the significant impact area (SIA) of the emissions increase with potential allowable emissions greater than the PSD significant emission rates (listed in Table 3), must be included in a new source review NAAQS analyses. SIA is defined as the region over which any exceedance of a PSD significant impact increment (listed in Table 3) occurs, based on each high-high concentration over five years of modeling (one year if on-site, representative data are available). In addition, all major sources with potential allowable emissions greater than 100 tons/yr outside of the SIA and within 50 km must also be included if they interact with the new source.

Whether to include a potentially interacting source can be determined using the '20D' approach. Under this approach, the modeler may exclude sources whose potential allowable emissions in tons/yr are less than 20 times the distance between the two sources in kilometers. Prior to commencement of final modeling, though, Ohio EPA must be advised as to what sources the modeler chooses to exclude using the 20D method. Ohio EPA reserves the right to require any or all of these sources to be included in a final analysis if Ohio EPA believes that any or all are potentially significant.

Major Source PSD Increment Analysis: All PSD sources located within an area where PSD baseline has been triggered or within the SIA of the new source, whichever is larger, must be included in the PSD increment analysis modeling inventory. PSD sources located outside of the baseline area or SIA which interacts with the new source must also be included. These sources may be screened using the 20D approach.

Inventory data should be obtained from the state emissions inventory system or the AIRS national data base system. Basic modeling source parameters (stack height or release height, diameter, temperature, exit velocity or volume flow, emission rate, etc.) are contained in these data systems.

The DAPC emissions inventory unit has placed several data sets on the Ohio EPA web page at: <http://www.epa.state.oh.us/dapc/aqmp/eiu/eiu.html>. While the later data sets have significant amounts of current information, it is important to check the 1990 and 1995 data bases which contain information on short term allowable emission rates.

The short term allowable rates and source capacities are included in these earlier data sets. These are important for determining maximum short term allowable emission rates for the significant sources consistent with Section 9.1 of the GAQM. If source information is missing or is suspect, you will need to contact the local air pollution agency or field office to obtain current, correct information.

Question 15: How do I model major sources in nonattainment areas to demonstrate net air quality improvement?

Answer 15: OAC 3745-31-25 discusses the requirements for determination of net air quality benefit for major sources wishing to locate in a nonattainment area (NAA). Both the rule and U.S. EPA guidance indicate the need for demonstrating area-wide benefit and progress toward attainment.

VOC emissions are not required to be modeled for net air quality benefit. All major PM and SO₂ emissions increases and corresponding offsetting emissions will need to be modeled for a net air quality benefit. The entire state is attainment for CO, NO_x and Pb so no net air quality benefit modeling is required.

In general, PM and SO₂ NAAs have undergone SIP modeling at some time and the state has identified receptor areas which were key for the SIP attainment demonstrations. In cases where the potential offsets could impact critical receptors, those receptors must show impacts less than or equal to zero. For the remaining receptors, the receptors within the significant impact area of the increasing emissions must, on average, show no net increase for each averaging period.

If greater than zero impacts at critical receptors or net area-wide increases are modeled, the applicant may present a complete NAAQS demonstration for the significant impact area of the project.

Question 16: Can I use SCREEN to model multiple sources?

Answer 16: While the SCREEN model is a single-source model, it can be used to develop a conservative estimate of the peak potential impact of emissions from multiple egress locations.

A conservative approach combines the peak impact from each individual SCREEN run as if the peak impact from each emission point occurred at the same point in space.

In the case of multiple identical stacks, all of the emissions can be assumed to come from one stack (modeled using the combined emission rate with the stack flow parameters for a single stack).

If the egress points are not identical, all of the emission could be assumed to be emitted from the 'worst case' emission point. Sometimes the determination of worst case is straightforward (e.g., shortest, coldest, lowest flow stack). In other situations, the choice may not be clear and the Local Air Agency, District Office or Central Office should be consulted.

The approaches described above will result in conservative estimates. If the source(s) does not pass using the above assumptions, less conservative approaches can be considered in consultation with the Local Air Agency, District Office or Central Office. A multisource refined model may also be appropriate to use to model the actual separation of emission points and estimate their combined peak impact.

Question 17: If multiple pollutants are being emitted, does an individual model run have to be performed for each pollutant?

Answer 17: If the emission characteristics are identical for each pollutant (all of the pollutants are emitted in the same proportion from each of the egress points) one run can be performed and the results can be adjusted. Gaussian models such as AERMOD, SCREEN and ISC are 'linear' models in that the impacts will vary proportionally to the emission rate. Therefore, in this example case, if one pollutant is being emitted at twice the rate of another pollutant, the impact of the second pollutant will be twice as high.

In the case of multiple pollutants being emitted from a single emission point, an emission rate of 1 gram per second can be modeled and the results multiplied by each allowable emission rate (expressed in grams per second) to determine the predicted ambient concentration of each of the pollutants.

If emission characteristics vary for different pollutants, or the pollutants do not vary proportionately from each egress point, then a separate modeling analysis for each pollutant is necessary.

Question 18: For PSD and non-PSD sources, can facilities be installed if modeling shows that more than ½ the available PSD increment is consumed?

Answer 18: The purpose of PSD is to keep clean areas clean. The intent of the one half increment portion of the policy is to allow future growth by preventing any single emissions increase from consuming all of the available increment.

Non-PSD sources still consume increment and increase background concentrations. Therefore, these emissions can also threaten future growth.

As such, it is Ohio EPA's practice that any new source, whether PSD or not, will not

consume more than one half the available PSD increment (In application, state-only permits do not involve modeling which would assess available increment, therefore, one half the increment is the effective goal.) .

In some cases, Ohio EPA will grant exceptions to this policy for new PSD or non-PSD sources where modeling predicts exceedances of one half of, but less than 83 percent of the available increment. (For example: If the available increment were 30 ug/m³, between 15 and 25 ug/m³.) Exceptions will be granted on a case-by-case basis (but only when public health will not be adversely affected or where modeling is results are suspect). The following are examples of where exceptions will be granted:

- 1) Modeling shows that the exceedance of the one half of the available increment occurs in a very localized area near the emissions source either due to the source parameters or due to downwash and, in the Ohio EPA's judgement, it is unlikely that other new sources located near the facility will significantly impact the same exceedance locations. In other words, if it is unlikely that another source would be negatively impacted by the exceedance then the Ohio EPA may grant the exception. An example of this would be a fugitive source with low release points having close proximity maximum impact areas that in the Ohio EPA's judgement would not be areas that other facilities would impact.
- 2) If the source is located such that it is unlikely in the Ohio EPA's judgement that any other major source would locate in the same area (for instance, in an extremely remote, rural area).
- 3) If the source is temporary and the increment consumed will become available in the near future for future growth (for instance, at a clean up site where the source will be operated for only a couple of years.)
- 4) If the source is locating in a 'brownfield' area and otherwise would locate in a greenfield site.

Question 19: What determines whether a locale is rural or urban?

Answer 19: The Guideline on Air Quality Models-(Appendix W of 40 CFR Part 51) outlines two methods by which an area can be categorized as either 'urban' or 'rural'. These methods rely on evaluating either the land use or population density within a three-kilometer radius circle around the subject source. Either of these methods is acceptable for the determination of the proper classification for that source, although the land use approach is preferred.

In Ohio, many counties have had significant SIP development modeling performed which included sources from across the county. Due to the inability of the models used to incorporate both rural and urban in a single run, a single, predominate classification

was assigned for the entire county. Therefore, if multiple facilities over a wider area are being modeled as part of a PSD or NAAQS analysis, the Central Office should be consulted as to the historic classification for the overall analysis so that a consistent approach will be maintained.

WFS/JTT/wfs

July 1, 2003

Appendix A.....pg 29

SCREEN/TSCREEN Model Application Guidance

Point Sourcepg 29

Area Sourcepg 30

Volume Sourcepg 30

TABLES

Table 1; Meteorological Assignmentspg 24

Table 2; National Weather Service Anemometer
Heights and Station Numbers.....pg 27

Table 3; Threshold Emission Rates and
Target Concentrationspg 28

Table 1

METEOROLOGICAL ASSIGNMENTS

(meteorological years 1987-1991 unless otherwise specified)

<u>COUNTY</u>	<u>SURFACE</u>	<u>MIXING HEIGHT</u>
ADAMS	Huntington	Huntington
ALLEN	Dayton	Dayton
ASHLAND	Akron	Pittsburgh
ASHTABULA	Erie	Buffalo
ATHENS	Parkersburg	Huntington (1973-1977)
AUGLAIZE	Dayton	Dayton
BELMONT	Pittsburgh	Pittsburgh
BROWN	Cincinnati	Dayton
BUTLER	Cincinnati	Dayton
CARROLL	Pittsburgh	Pittsburgh
CHAMPAIGN	Dayton	Dayton
CLARK	Dayton	Dayton
CLERMONT	Cincinnati	Dayton
CLINTON	Cincinnati	Dayton
COLUMBIANA	Pittsburgh	Pittsburgh
COSHOCTON	Columbus	Pittsburgh
CRAWFORD	Columbus	Dayton
CUYAHOGA	Cleveland	Buffalo
DARKE	Dayton	Dayton
DEFIANCE	Fort Wayne	Flint
DELAWARE	Columbus	Dayton
ERIE	Cleveland	Buffalo
FAIRFIELD	Columbus	Dayton
FAYETTE	Columbus	Dayton
FRANKLIN	Columbus	Dayton
FULTON	Toledo	Flint
GALLIA	Huntington	Huntington
GEAUGA	Cleveland	Buffalo
GREENE	Dayton	Dayton
GUERNSEY	Pittsburgh	Pittsburgh
HAMILTON	Cincinnati	Dayton
HANCOCK	Toledo	Dayton
HARDIN	Dayton	Dayton

METEOROLOGICAL ASSIGNMENTS

HARRISON	Pittsburgh	Pittsburgh
HENRY	Toledo	Flint
HIGHLAND	Cincinnati	Dayton
HOCKING	Columbus	Huntington
HOLMES	Akron	Pittsburgh
HURON	Cleveland	Buffalo
JACKSON	Huntington	Huntington
JEFFERSON	Pittsburgh	Pittsburgh
KNOX	Columbus	Dayton
LAKE	Cleveland	Buffalo
LAWRENCE	Huntington	Huntington
LICKING	Columbus	Dayton
LOGAN	Dayton	Dayton
LORAIN	Cleveland	Buffalo
LUCAS	Toledo	Flint
MADISON	Columbus	Dayton
MAHONING	Youngstown	Pittsburgh
MARION	Columbus	Dayton
MEDINA	Akron	Pittsburgh
MEIGS	Parkersburg	Huntington (1973-1977)
MERCER	Fort Wayne	Dayton
MIAMI	Dayton	Dayton
MONROE	Parkersburg	Pittsburgh (1973-1977)
MONTGOMERY	Dayton	Dayton
MORGAN	Parkersburg	Huntington (1973-1977)
MORROW	Columbus	Dayton
MUSKINGUM	Columbus	Pittsburgh
NOBLE	Parkersburg	Pittsburgh (1973-1977)
OTTAWA	Toledo	Flint
PAULDING	Fort Wayne	Dayton
PERRY	Columbus	Huntington
PICKAWAY	Columbus	Dayton
PIKE	Huntington	Huntington
PORTAGE	Akron	Pittsburgh
PREBLE	Dayton	Dayton
PUTNAM	Fort Wayne	Dayton
RICHLAND	Columbus	Dayton
ROSS	Columbus	Dayton

METEOROLOGICAL ASSIGNMENTS

SANDUSKY	Toledo	Flint
SCIOTO	Huntington	Huntington
SENECA	Toledo	Dayton
SHELBY	Dayton	Dayton
STARK	Akron	Pittsburgh
SUMMIT	Akron	Pittsburgh
TRUMBULL	Youngstown	Pittsburgh
TUSCARAWAS	Akron	Pittsburgh
UNION	Columbus	Dayton
VAN WERT	Fort Wayne	Dayton
VINTON	Huntington	Huntington
WARREN	Cincinnati	Dayton
WASHINGTON	Parkersburg	Huntington (1973-1977)
WAYNE	Akron	Pittsburgh
WILLIAMS	Toledo	Flint
WOOD	Toledo	Flint
WYANDOT	Columbus	Dayton

Table 2

**National Weather Service Anemometer Heights
and Station Number**

<u>Site</u>	<u>Anemometer Height</u>	<u>Station Number</u>
Akron/Canton	20 feet	14895
Cincinnati/Covington	20 feet	93814
Cincinnati/Abbe Obs.	51 feet	93890
Cleveland	10 meters	14820
Columbus	20 feet	14821
Dayton	22 feet	93815(surface)
Dayton (Wright Pat)	NA	13840(upper air)
Mansfield	20 feet	14891
Toledo	30 feet	94830
Youngstown	20 feet	14852
Buffalo, NY	10 meters	14733
Erie, Pa.	20 feet	14860
Flint, Mi.	21 feet	14826
Fort Wayne, In.	20 feet	14827
Huntington, WV	20 feet	03860
Charleston WV	117 feet	13866
Elkins WV	20 feet	13729
Pittsburgh, Pa.	20 feet	94823
Parkersburg, WV	100 feet	13867

**Table 3
Federal and State Modeling Standards and Significant Emission Rates**

POLLUTANT	AVERAGING PERIOD	National Ambient Air Quality Standards (NAAQS) (ug/m ³)						OHIO	OHIO	
					PSD	PSD	PSD	MODELING	SIGNIFICANT	OHIO
				CLASS II	SIGNIFICANT	SIGNIFICANT	MONITORING	SIGNIFICANT	IMPACTS	ACCEPTABLE
				PSD	EMISSION	IMPACT	DE MINIMIS	EMISSION	UNDER	INCREMENTAL
				INCREMENTS	RATES	INCREMENTS	CONC	RATES	3745-31-01(vv)	IMPACT
	PRIMARY	SECONDARY	(ug/m ³)	(tons/year)	(ug/m ³)	(ug/m ³)	(tons/year)	(ug/m ³)	(ug/m ³)	
PM10	Annual	50 a	c	17 a	15	1 h	-	10		8.5 a
	24-Hour	150 b	c	30 b	--	5 h	10 h	--	10 (24-hr TSP) i	15 b
Sulfur Dioxide	Annual	80 a	c	20 a	40	1 h	--	25		10 a
	24 Hour	365 b	c	91 b	--	5 h	13 h	--	15 i	45.5 b
	3-Hour	--	1300 b	512 b	--	25 h	--	--		256 b
Nitrogen Dioxide	Annual	100 a	c	25 a	40	1 h	14 h	25	15 (24-hr) i	12.5 a
Ozone	1-Hour	244 d	c	--	40 e	--	--			
Carbon Monoxide	8-Hour	10,000 b	c	--	100	500 h	575 h	100	575ia	2500 b
	1-Hour	40,000 b	c	--	--	2000 h		--		10000 b
Lead	Calendar Quarter	1.5 a	c	--	0.6	--	0.1 h	0.6	0.1 i	0.375 a
Toxics Listed by ACGIH f	1-Hour	--	--	--	--	--	--	1		g, a

a Concentration not to be exceeded

b Concentration not to be exceeded more than once per year

c Same as primary NAAQS.

d Not to be exceeded on more than one day per year, three year average.

e Emissions of volatile organic compounds.

f Any toxics included in the latest handbook of The American Conference of Governmental Industrial Hygienists.

g Value calculated by procedure outlined in current version of the Ohio EPA Division of Air Pollution Control document entitled "Review of New Sources of Air Toxic Emission"

h Peak concentration.

i Concentration that initiates PTI requirements

Appendix A

SCREEN/TSCREEN Model Application Guidance

The type of SCREEN source to be chosen is dependant on how the emissions leave the source (if the source is not enclosed) or how they leave the building or enclosure if emitted within a building or enclosure. Once the egress points are identified and characterized, one of the following source types is applied to the emissions at the point of egress (stack, window, vent, etc.)

The following information identifies the SCREEN/TSCREEN model choices to be used when modeling for Ohio new source review. Since the TSCREEN model does not directly identify which release scenarios lead to the use of the SCREEN model, "TSCREEN pathways" are identified to assist TSCREEN users in making scenario choices that will lead to the SCREEN model and the desired source type.

Point Source

TSCREEN pathways; There are several TSCREEN release scenarios which utilize the SCREEN3 point source option including Gaseous Release Type, Stacks, Vents, Conventional Point Sources or Particulate Matter Release Type, Stacks, Vents.

- Emission rate (g/s)
- Stack Height (above ground, not roof (m))
- Stack inside diameter (m, diameter of equivalent area circle if stack is not round)
- Stack exit velocity (m/s) or flow rate (ACFM or m³/s)
- Stack gas temperature (K)
- Ambient temperature (use default of 293 K)
- Receptor height above ground (use 0, ground level)
- Urban/Rural (based on land use within 3 km of the source)
- Building downwash (Building information is necessary if stack is within the influence of a building: i.e., within five times the lesser building dimension)
- Do not consider building cavity calculations. **Note:** After mmm dd, 2002, AERMOD will replace ISC and be the only acceptable refined model. This model does incorporate building wake and cavity effects. After mmm dd, 2002, users of SCREEN will also need to consider the building cavity calculations when determining peak impacts.
- Complex terrain (yes if terrain above stack height is present in the potential impact area of the source)
- Simple or flat (yes for simple: if terrain above stack base is present in the potential impact area of the source. When in doubt, say yes and perform the analysis)
- Choice of meteorology (option 1, full meteorology)
- Automated distance array (yes, minimum distance (m) begins at "ambient air" (usually the fence line) and should extend to a point which ensures that the

- maximum concentration has been found, up to a maximum of 50,000 m)
- Discrete distance option (used for informational purposes only)
- Fumigation Option (fumigation calculations are not used for state permit modeling)

Area Source

TSCREEN pathway; There are several TSCREEN pathways which utilize the SCREEN3 area source option including Particulate Matter Release Type, Fugitive/Windblown Dust Emissions or Storage Piles or Gaseous Release Type, Multiple Fugitive Sources. The TSCREEN pathways **do not** allow the characterization of non-square area sources which is now an option with SCREEN3.

General option choices are the same as for point source except for the following;

- Emission rate (g/s/m²)
- Source height (mean height of source, m)
- Length of longer side of rectangular area, (m)
- Length of shorter side of rectangular area, (m)
- Wind direction search (yes)

Volume Source

TSCREEN pathway:(the SCREEN volume source option is not available through TSCREEN)

General options choices are the same as for point source except for the following;


- Initial lateral dimension (modified per table below (m))
- Initial vertical dimension (modified per table below (m))
- Height of release (the midpoint of the opening (m))

SUMMARY OF SUGGESTED PROCEDURES FOR ESTIMATING INITIAL LATERAL DIMENSIONS (σ_{y0}) AND INITIAL VERTICAL DIMENSIONS (σ_{z0}) FOR VOLUME SOURCES

Description of Source	Initial Dimension
(a) Initial Lateral Dimensions (σ_{y0})	
Single Volume Source	$\sigma_{y0} =$ length of side divided by 4.3
(b) Initial Vertical Dimensions (σ_{z0})	
Surface-Based Source ($h_e \sim 0$)	$\sigma_{z0} =$ vertical dimension of source divided by 2.15
Elevated Source ($h_e > 0$) on or Adjacent to a Building	$\sigma_{z0} =$ building height divided by 2.15

Elevated Source ($h_e > 0$) not on or
Adjacent to a Building

$\sigma_{z0} =$ vertical dimension of source
divided by 4.3



98
APPROXIMATELY
25.5 ACRES

LIMIT OF WETLANDS
AREA OF WETLAND DISTURBANCE
96.2 ACRES

99
APPROXIMATELY
25.5 ACRES

95
APPROXIMATELY
14.2 ACRES

AREA OF WETLAND DISTURBANCE
40.5 ACRES

96
APPROXIMATELY
25.4 ACRES

97
APPROXIMATELY
25.4 ACRES

34 32 30
33 31 29 28

1500' FROM
PROPERTY LINE

0.9 ACRES ±
PUBLIC
DROP OFF

FLARES
AND
COLLECTOR
2 ACRES

TURBINE
BUILDING
1.9 ACRES ±

LEACHATE
TANKS
0.6 ACRES ±

DEEP WELL
INJECTION
0.7 ACRES ±

SCALES
PROPOSED POND
5.1 ACRES

MAINTENANCE
BUILDING
0.2 ACRES ±






Figure 3-1 Everglades Receptors



Okeechobee Landfill, Inc.

Figure 3-2 Biscayne Bay Receptors



Okeechobee Landfill, Inc.

Figure 3-3 Big Cypress Receptors

